Pneumatic Instrumentation Equipment



For Pneumatic Control in

Process Automation



- Flow capacity: 65000 L/min (ANR) Outlet air pressure dew point: 10°C
- Flow capacity: 780 L/min (ANR) Outlet air atmospheric pressure dew point: -30°C

Air Preparation Filters



- Micro Mist Separator with Prefilter
- Nominal filtration rating: 0.01 μm Odor Removal Filter
- Outlet oil mist concentration: Max. 0.0032 ppm

Detection Conversion Unit Page 74

Pressure Sensors



■ General fluids: –0.1 to 15 MPa

Flow Sensors



- Air: 0.2 to 12000 L/min (ANR)
- General fluids: 0.5 to 250 L/min (ANR)

Industrial Filters Page 101








- Flow capacity: Max. 3800 L/min (ANR)
- Nominal filtration rating: 0.5 to 120 μm

Compressor



Factory Automation





Operation Unit














In principle, SMC products cannot be used outdoors.

INDEX

	Positioners	Page 6
	Electro-Pneumatic Positioner/IP8000/8100 Smart Positioner/IP8001/8101	Page 7
	Pneumatic-Pneumatic Positioner/IP5000/5100 Cylinder Positioner/IP200	Page 32
<u> </u>	Regulators	Page 37
	Filter Regulator / IW	Page 38
	Filter Regulator /1301	
Ĭ	Filter Regulator: For Low Temperature Environment (–30 to 60°C)/High Temperature Environment (–5 to 80°C)/AW-X430 Filter Regulator: Stainless Steel 316 and Special Temperature Environment (–40°C) Specifications/AW30/40-	
	Precision Regulator/IR ······	
	Relays/Valves	Page 52
	Relay	
	Booster Relay/IL100······Valves	Page 53
	Lock-Up Valve /IL201/211/220 ·····	Page 56
	Electro-Pneumatic Transducers	Page 59
	Electro-Pneumatic Transducer/IT600	
	Electio-Friedinatic Itansudcei/11000	raye ou
= =	Actuators	Page 62
	P Cylinder (Cylinder with Positioner)/CPA2	Page 63
	CPS1	Page 63
	Detection Conversion Unit	Page 74
	Pressure Switches/Sensors	
*	Pressure Switch/Micro Switch Type/IS100	
	Pressure Switch/Reed Switch Type/IS10 Pressure Switch/Micro Switch Type/IS3000	Page 77
	General Purpose Pressure Switch/Snap Switch Type/ISG	
	2-Color Display High-Precision Digital Pressure Switch/ ZSE/ISE30A ····································	
	2-Color Display Digital Pressure Switch/ISE70/75(H)	Page 77
	2-Color Display Digital Pressure Switch/ ZSE/ISE80	Page 77
	Flow Switches/Sensors 2-Color Display Digital Flow Switch/PFM ····································	Pogo 79
	2-Color Display Digital Flow Switch/ PFMB	····· Page 76
	Digital Flow Switch for Air/ PF2A	Page 78
	3-color Display Digital Flow Switch for Water/PF3W	Page 78
	3-color Display Electromagnetic Type Digital Flow Switch/LFE	Page 78
	Diaphragm Style Flow Switch/IFW5	
	Paddle Style Flow Switch/IF3·····	Page 78
	Solenoid Valves	Page 79
	Directional Control Valves	
000	NAMUR Interface 3 Port Solenoid Valve/VFN200N NAMUR Interface 5 Port Solenoid Valve/VFN2000N	Page 80
	NAMUR Interface 3/5 Port Solenoid Valve/	Fage 63
	IP67 Compliant, Hygienic Design Type/VFN2120N-X23/-X36······	Page 90
	Intrinsically Safe Explosion-proof System 5 Port Solenoid Valve/51-SY	Page 96
	Explosion-proof Type 3/5 Port Solenoid Valve/50-VFE/50-VPE	Page 96
	Fluid Control Equipment Direct Operated 2 Port Sciencid Volve (VX2)	D 00
	Direct Operated 2 Port Solenoid Valve/VX2 Pilot Operated 2 Port Solenoid Valve/VXD	





	Air Preparation Equipment	Page 97
	Aftercoolers	
	Air Cooled Aftercooler/HAA	Page 98
	Water Cooled Aftercooler/HAW	····· Page 98
*	Air Tanks	
	Air Tank/ VBAT	Page 98
	Air Tank/ AT	····· Page 98
	Air Dryers Refrigerated Air Dryer/IDF/IDU□E, D	Dogo 00
	Refrigerated Air Dryer/Large Size Series/IDF□F	
	Refrigerated Air Dryer: For Use in Europe, Asia, and Oceania/IDFA	
	Refrigerated Air Dryer/Large Size Series: For Use in Europe, Asia, and Oceania/IDFA□F	•
	Refrigerated Air Dryer: For Use in North, Central and South America/IDFB	
	Heatless Air Dryer/ID	
	Membrane Air Dryer/IDG ······	
	Filters	
	Water Separator/AMG·····	Page 99
	Main Line Filter/AFF	
	Mist Separator/AM	····· Page 99
	Micro Mist Separator/AMD	
	Micro Mist Separator with Pre-filter/AMH	
	Super Mist Separator/ AME Odor Removal Filter/ AMF	
	Odol Hemoval Filter/Aim	1 age 100
	Industrial Filters	Page 101
-	Industrial Filters	
-	Industrial Filter/ FGD	Page 102
	Industrial Filter/ FGE	
¥	Industrial Filter/FGG	····· Page 102
	Bag Filter/ FGF	
	High Precision Filter for Liquids/ FGH	
	Quick Change Filter/FQ1	···· Page 102
	Elements	
	Sintered Metal Filter Elements/EB/ES	Page 103
	Fiber Elements/ EH/EHM/EHK Paper Elements/ EP	
	Micromesh Elements/EM	Page 103
	Wild Officer Elements Em	r age 100
	Piping Materials	Page 104
	Tubing	
()	Double-layered Tube for Instrumentation Device (Single-tubed/Double-tubed)/IN-241	····· Page 105
	T0604 to T1075-X120/121/166	6 ·· Page 105
	Reinforced Corrugated Cardboard Specification: Longer Length Reel/T0604-X64/TH0604-X64	I
	Polyurethane Coil Tubing/TCU	
	Longer Length Reel/-X3	····· Page 110
	Fittings/S Couplers	
	Stainless Steel 316 One-touch Fittings/KQG2	
	Stainless Steel 316 Insert Fittings/KFG2	
	S Couplers: Stainless Steel Type/KKA	···· Page 110



Pneumatic Instrumentation Equipment

Positioners



Electro-Pneumatic Positioner/IP8000/8100	Page 7
Smart Positioner/IP8001/8101	Page 7
Pneumatic-Pneumatic Positioner/IP5000/5100	Page 32
Cylinder Positioner/IP200	Page 35


Series IP8

Electro-Pneumatic Positioner/Smart Positioner (Lever type/Rotary type)

[Option]

Dustproof / Waterproof

Passed by external organization on **JIS F8007** (conforms to IEC 60529) **IP65**



A centralized exhaust system employs the combination of the check valve and the labyrinth effect enhancing both dustproof and waterproof performance.

Monitoring function

Electro-Pneumatic Positioner

· Opening current transmission analog (4 to 20 mA DC) continuous output

Smart Positioner

- · Alarm point output function (2 points)
- · Analog (4 to 20 mA DC) continuous output

With external scale plate (Rotary type, Bottom mounting)



External scale plate

Improved visibility of opening indicator

Electro-Pneumatic Positioner

Universal mechanically controlled type Series IP8000/8100



Explosion-proof construction

Electro-Pneumatic	TIIS explosion-proof construction (Exd II BT5)	
Positioner	ATEX intrinsically safe explosion-proof construction (II 2G Ex ib II CT5/T6)	
Smart Positioner	ATEX intrinsically safe explosion-proof construction (II 1G Ex ia II CT4/T5/T6)	

With internal opening indicator plate



Body with LCD window

(Smart Positioner)



Smart Positioner

Electronically controlled easy-adjustment transmitting type Series IP8001/8101



(Rotary type)



Smart Positioner

Series IP8001/8101

Built-in microcomputer and sensor allows easy remote parameter change and monitoring.



IP8101 (Rotary type)

- · Internal push button for easy setting of various parameters (Refer to parameter list)
- · Zero point/span adjustment easier than with previous mechanical positioners

Parameter	List
i aiaiiiotoi	

Notes	No	Parameter	Description
	1	Positive operation/ reverse operation setting	Change operation direction with regard to input signal Change to internal components, piping not possible
	2	Split range setting	Change range of input signal
	3	Preferred zero point/span adjustment setting	Change actuator stroke range with regard to input signal
	4	Forced full close/full open setting	To ensure valve closure, force actuator opening to be 0% or 100% with a preferred input signal.
Standard equipped functions	5	Valve characteristic setting	Select from these 6 valve characteristics Linear characteristic Equality % characteristic (2 kinds) Quick open characteristic (2 kinds) User preferred point setting (11 points)
	6	PID constant setting	Change PID constant
	7	Calibration setting	Zero point/span adjustment, Auto PID constant setting, input signal display value calibration, etc.
	8	Alarm 1 output setting	Set upper/lower stroke limits for actuator from which alarm is
Optional equipped	9	Alarm 2 output setting	output
functions	10	Analog (4 to 20 mA DC) output setting	Set increase/decrease direction for 4 to 20 mA DC output with regard to actuator stroke

Full Output Functions

Selecting models with output functions by model selection selects with alarm point output function (2 points) and analog (4 to 20 mA DC) continuous output function. This will allow remote detection of operating abnormalities.

Control State Display

Positioning, deviation, and input value are displayed (numerically) on the internal LCD, allowing visual verification of the control state.



Display example

Positioning (%)

Input value (%) 5

Deviation (%) E

Handles 2-line Input for Existing Equipment

Control furnished with conventional 2-line input signal (4 to 20 mA DC) not requiring separate power source.

HART Transmission Function

HART transmission function can be designated by model selection.

Allows remote monitoring and setting change of posi-

Intercompatible Installation

Dimensions of mounting parts same as previous mechanical series IP6000/IP8000 Electro-Pneumatic Positioner. External feedback lever and fork lever-type fitting for joining actuator and positioner are therefore also the


Energy Saving Product

Lever-type features 60% reduced air flow consumption compared with IP8000.

Electro-Pneumatic Positioner (Electro-Pneumatic Positioner (Lever type/Rotary type) Series IP8000/8100

- Enclosure: JISF8007 IP65 (conforms to IEC 60529)
- Monitoring function (Opening current transmission 4 to 20 mA DC, Accessory J, JR)
- Explosion-proof construction/Electro-pneumatic positioner: TIIS explosion-proof construction (Exd II BT5), ATEX intrinsically safe explosion-proof construction (II 2G Ex ib II CT5/T6)

How to Order



Accessories Note 2)

Symbol	Accessories	Applicable model		
	Accessories	IP8000	IP8100	
Nil	None (Standard)	•	•	
Α	ø0.7 Output restriction with pilot valve Note 3)	•	•	
В	ø1.0 Output restriction with pilot valve Note 3)	•	•	
С	Fork lever-type fitting M Note 4)	_	•	
D	Fork lever-type fitting S Note 5)	_	•	
E	For stroke 35 to 100 mm with lever unit Note 6)	•	_	
F	For stroke 50 to 140 mm with lever unit Note 6)	•	_	
G	Compensation spring (A) Note 7)	•	•	
Н	With external scale plate Note 8)	_	•	
J	With opening current transmission (4 to 20 mA DC)/Positive operation Note 9)	_	•	
JR	With opening current transmission (4 to 20 mA DC))/Reverse operation Note 9)	_	•	

Note 1) For construction No.1(with terminal box), the ambient and fluid temperatures are as follows:

• Exd II BT5 — −20 to 60°C

 \bullet Non-explosion proof (non hazardous locations only) — –20 to 80°C The positioner body is EXd $\rm II$ BT5 labeled.

Note 2) If two or more accessories are required, the part numbers should be made according to alphabetical order. (ex. IP8100-010-AG)

Note 3) "A" is applied to approx 90cm³-capacity actuator.

"B" is applied to approx 180cm3-capacity actuator.

Note 4) Fork lever-type fitting MX (Connection thread: M6 x 1) for IP8100-0 \square 0- \square -X14.

Note 5) Fork lever-type fitting SX (Connection thread: M6 x 1) for IP8100-0 \square 0- \square -X14.

Note 6) Standard lever is not attached.

Note 7) It is to be used together with "A" or "B" when tending to overshoot by the use of "A" or "B".

It is mounted to the body as a replacement of the standard compensation spring.

Note 9) Symbol J/JR is with terminal box, non-explosion proof specification. Select 1 for Construction. Positive operation signifies clockwise rotational direction by the main actuator shaft when positioner cover is viewed from the front.

Note 10) Combination of L and W is not available.




Smart Positioner (Lever type/Rotary type)

Series IP8001/8101

Auto calibration

- HART transmission function
- Enclosure: JISF8007 IP65(conforms to IEC 60529)
- Monitoring function
- Explosion-proof construction/ATEX intrinsically safe explosion-proof construction (II 1G Ex ia II CT4/T5/T6)

How to Order



Sn	ecifi	cati	one

0	Basic type
2	With output function {Analog (4 to 20 mA DC) output + Alarm output x 2}
3	With HART transmission function

1.0 MPa

	_	_		
ш				

● CE marking				
Nil	_			
Q	CE marked product			

ATEX temperature

Symbol

Nil

T6

ATEX

temperature

T4

T5/T6

Applicable model

IP8001 IP8101

Connection

Symbol	Air	Electric
Nil	Rc1/4	G1/2
M Note)	Rc1/4	M20 x 1.5
N	Rc1/4	1/2NPT
1	1/4NPT	G1/2
2 Note)	1/4NPT	M20 x 1.5
3	1/4NPT	1/2NPT
4	G1/4	G1/2
5 Note)	G1/4	M20 x 1.5
6	G1/4	1/2NPT

Note) When the symbol is M, 2, or 5 for 52-ATEX directive items, a blue cable gland is included with the electrical

ccessories Note 1)

	Applicable model							
Symbol	Accessories	Applicat	ie modei					
Cyrribor	Accessories	IP8001	IP8101					
Nil	None (Standard)	•	•					
С	Fork lever-type fitting M	_	•					
D	Fork lever-type fitting S	- •						
E	For stroke 35 to 100 mm with lever unit Note 2)	•	_					
F	For stroke 50 to 140 mm with lever unit Note 2)		_					
Н	With external scale plate Note 3)	_ •						
W	Body with LCD window	•	•					

Note 1) If two or more accessories are required, the part numbers should be given in alphabetical order. (ex. IP8101-010-CH)

Note 2) Standard lever is not attached.

Note 3) For side mounting, select "-W" and check the control position by viewing the LCD display value.

Series IP8

Specifications Note 1)

Type		000	IP8	100	IP8001	IP8101	
		Electro-Pneum	atic Positioner		Smart Po	ositioner	
	Lever type le	ver feedback	Rotary type o	am feedback	Lever type	Rotary type	
Item	Single action	Double action	Single action	Double action	Single action /	Double action	
Input current				4 to 20 mA DC ((Standard) Note 2)		
Min. operating current		_	_		3.85 mA D	C or more	
Intra-terminal voltage		_	_		12 V DC (equivalent to 600 Ω i	nput resistance, at 20 mA DC)	
Max. supplied power		_	_		1 W (Imax: 100 mA DC, Vmax: 28 V DC)		
Input resistance		235 ±15 Ω (4	to 20 mA DC)		_	-	
Supply air pressure			0.14 to (0.7 MPa	0.3 to 0.7 MPa		
Standard stroke	10 to 85 mm (Allowable of	deflection angle 10 to 30°)	60 to 10	0° Note 3)	10 to 85 mm (Allowable deflection angle 10 to 30°)	60 to 100° Note 3)	
Sensitivity Note 4)	Within 0.1% F.S.	Within 0.1% F.S. Within 0.5% F.S. Within 0.2% F.S.			2% F.S.		
Linearity Note 4)	Within ±1% F.S.		Within ±2% F.S.		Within ±	1% F.S.	
Hysteresis Note 4)	Within 0.75% F.S.		Within 1% F.S.		Within 0.	5% F.S.	
Repeatability Note 4)	Within ±0			Within ±0).5% F.S.		
Coefficient of temperature		Within 0.1% F.S./°C			Within 0.05% F.S./°C		
Supply pressure fluctuation	on Within 0.3% F.S./0.01 MPaNote 5)			ote 5)			
Output flow Note 6)	80 L/min (ANR) or more (SUP = 0.14 MPa) 200 L/min (ANR) or more (SUP = 0.4 MPa)			= 0.4 MPa)			
Air consumption Note 6)	5 L/ı	min (ANR) or les	s (SUP = 0.14 N	/IPa)	2 L/min (ANR) or less (SUP = 0.14 MPa)	11 L/min (ANR) or less	
All consumption	11 L/min (ANR) or less (SUP = 0.4 MPa)			/IPa)	4 L/min (ANR) or less (SUP = 0.4 MPa)	(SUP = 0.4 MPa)	
				General structu	re: -20 to 80°C		
Ambient and fluid	TIIS explosion-proof: -20 to 60°C						
temperature	ATEX intrinsically safe explosion-proof: —20 to 80°C (T5)				ATEX intrinsically safe explosion-proof –20 to 80°C (T4/T5)		
	-20 to 60°C (T6)					–20 to 60°C (T6)	
		-40 to 60°C (T6)/-L type low-temperature specification					
Explosion proof construction Note 7)		explosion-proof co safe explosion-pro			ATEX intrinsically safe exp		
	,		•		,	<u> </u>	
ATEX intrinsically safe explosion-proof parameter (current circuit)	(Ji ≤ 28 V, Ii ≤ 12 Ci ≤ 0 nF,	•	V	Ui ≤ 28 V, li ≤ 100 Ci ≤ 12.5 nF,	,	
Exterior covering enclosure Note 8)		CI ≤ U IIF,		NOT IDEE (confo	L	LI S I.O IIII	
Transmission method Note 7)			JISFOL	007, IP65 (COIIIO	rms to IEC Pub.60529) HART tran	nominaion	
Air connection port Note 9)			C 1// female the	read NPT 1/4 fo	male thread, G 1/4 female thread		
Electrical connection port Note 9)					nale thread, NPT 1/2 female thre		
Material/coating					inish with denatured epoxy resin	au	
Weight	2 4 kg (\Mith	nout terminal box			2.6	ka	
Note 1) Specification values are			, , ,		there is no output changes due to n	<u> </u>	

Note 1) Specification values are given at normal temperature (20°C).

Note 9) Thread type can be specified by model selection.

Optional Specifications

	Туре	IP8100-0□1-J/JR (Non-explosion proof)	IP8□01-0□2 (Non-explosion proof)	52-IP8□01-0□4	
Item		Electro-Pneumatic Positioner	Smart Positioner		
	Wiring		2-line		
Analog	Output signal		4 to 20 mA DC		
	Power supply voltage	12 to 35 V DC	10 to 28	3 V DC	
output	Load resistance	(Power supply voltage -12 V) ÷ 20 mA DC or less	s 0 to 750 Ω		
	Accuracy	±2% F.S. or less Note 1)	±0.5% F.S. or less Note 2)		
	Hysteresis	Within 1% F.S.	_		
	Wiring	_	2-line		
	Applicable standards	_		DIN19234/NAMUR Standard	
	Power supply voltage	_	10 to 28 V DC	5 to 28 V DC	
Alarm output 1, 2	Load resistance	_	10 to 40 mA DC	(Constant current output)	
output 1, 2	Alarm ON	_	$R = 350 \Omega \pm 10\%$	≥ 2.1 mA DC	
	Alarm OFF (Leakage current)	_	0.5 mA DC or less	≤ 1.2 mA DC	
	Response time	_	50 msec	or less	

Note 1) Indicates analog output accuracy with respect to actuator angle.

Note 2) Indicates analog output accuracy with respect to LCD display position value (P value).



Note 2) 1/2 Split range (Standard)

Note 3) Stroke adjustment: 0 to 60°, 0 to 100°

Note 4) Characteristics relating to accuracy differ depending on combination with other constituent loop equipment, such as positioners and actuators.

Note 5) While there is no output changes due to pressure fluctuations, when the pressure supply setting is changed following calibration, once again adjust balance current and perform calibration.

Note 6) (ANR) indicates JIS B0120 standard air.

Note 7) Model selection required for explosion proof construction and HART transmission.

Note 8) For IP66 compliant products, refer to pages 25 to 28.


Accessory/Option


Pilot valve with output restriction (IP8000/8100)

In general, mounting on a small-size actuator may cause hunting. For prevention, a pilot valve with a built-in output restriction is available. The restriction is removable.

Actuator capacity	Orifice size	Part number	Pilot unit part number	Model selection accessory
90 cm ³	ø0.7	P36801080	P565010-18	Α
180 cm ³	ø1	P36801081	P565010-19	В

Note) Output orifice not required for Smart Positioner regardless of actuator capacity.





Restrictor mounting diagram

Pilot valve bottom view


Fork lever-type fittings (IP8100/8101)

2 kinds of rotary type IP8100/8101 fork lever-type fittings, that differ by installation dimensions dependent on bracket installation method, and 2 kinds of installation portion thread sizes, are available.

When installing on the side surface, using fork lever assembly M provides interchangeability with the installation dimensions of SMC IP610 positioner. When installing on the rear surface, using fork lever assembly S also provides interchangeability with the installation dimensions of SMC IP610 positioner.

Part name	Unit number	Installation portion thread size	Model selection accessory
Fork lever assembly M	P368010-24	M8 x 1.25	С
Fork lever assembly S	P368010-25	IVIO X 1.25	D
Fork lever assembly MX	P368010-36	M6 x 1	C Note)
Fork lever assembly SX	P368010-37	IVIOXI	D Note)

Note) Installation portion thread size is M6 x 1 for IP8100-0 \square 0-X14 when accessory C or D are selected.



Side mounting with the fork lever assembly $M\square$


Rear mounting with the fork lever assembly $S\square$

External feedback lever (IP8000/8001)

Different feedback levers are available dependent upon valve strokes. Order according to the valve stroke.

Feedback lever types


Stroke	Unit n	umber	Size M	Sizo N	Model selection
Stroke	IP8000	IP8001	SIZE IVI	SIZE IN	accessory
10 to 85 mm	P368010-20	P565010-323	125	150	Standard accessory
35 to 100 mm	P368010-21	P565010-324	110	195	E
50 to 140 mm	P368010-22	P565010-325	110	275	F
6 to 12 mm	P368010-260	P565010-329	75	75	Available as special order



Resin connector (Non-explosion proof specification)


Optional cable connectors are available for different cable sizes. These are not for explosion proof applications. Recommended for use with indoor applications.


Part name	Part number	Suited cable outer diameter
Resin-made cable clamp unit (A)	P368010-26	ø7 to ø9
Resin-made cable clamp unit (B)	P368010-27	ø9 to ø11



Series IP8□

Exploded View







Electro-Pneumatic Positioner Smart Positioner Series IP8

Piping Note) When the input signal is discontinued, the pressure of OUT1 decreases, and the pressure of OUT2 increases.

IP8000/Lever type




IP8100/Rotary type




Piping

Note) When the input signal is discontinued, the pressure of OUT1 decreases, and the pressure of OUT2 increases. Caution is also similarly required when changing the control direction in parameter mode.

IP8001/Lever type



IP8101/Rotary type




INI-224-0-56


Installation

IP8000/8001 (Lever type)

1. Create brackets that are appropriate for the positioner and diaphragm valve mounting methods, and affix it firmly using the mounting hole on the side or rear surface.




2. The feedback lever that detects the displacement of valve stems should be mounted at a position so that the lever is at right angles to the valve stem for an input current of 50%. The figure is the configuration viewed from the front.



Brackets for lever type positioners, which are compliant with NAMUR and DIN/IEC 60534-6-1 are now available.


NAMUR and DIN/IEC 60534-6-1 are now available.				
Description	Part no.			

Bracket (NAMUR compliant) single unit



IP8100/8101 (Rotary type)

1. The positioner should be mounted so that the feedback shaft is aligned with the shaft of the rotary actuator.






Principle of Operation


IP8000/Lever type

When the input current increases, (11) the plate spring of (12) the torque motor will work as a pivot, (13) armature will receive a counter clockwise torque, (4) the counter weight will be pushed to the left, the clearance between (6) the nozzle and (5) the flapper will increase, and the nozzle back pressure will decrease. Consequently, (7) the exhaust valve of (1) the pilot valve moves to the right, the output pressure of OUT1 increases and (15) the diaphragm moves downwards. The motion of (15) the diaphragm acts on (10) the feedback spring through (8) the feedback lever, (14) the transmission lever and (9) the span adjustment lever to rest at the balance position generated by the input current. (2) The gain suppression spring is for direct feedback of the motion of (7) the exhaust valve to (4) the counter weight to increase the stability of the loop. The zero point should be adjusted by change of (3) the zero adjustment spring tension.

Single action positive operation





Block diagram



IP8100/Rotary type

When the input current increases, (12) the plate spring of (13) the torque motor will work as a pivot, (14) armature will receive a counter-clockwise torque, (4) the counter weight will be pushed to the left and the clearance between (6) the nozzle and (5) the flapper will increase, and the nozzle back pressure will decrease. Consequently, (7) the exhaust valve of (1) the pilot valve moves to the right, the output pressure of OUT1 increases that of OUT2 decreases and (16) the rotary actuator moves. The motion of (16) the actuator acts on (10) the feedback spring through (11) the feedback shaft, (8) the cam, (9) the span adjustment lever and (15) transmission lever to rest at the balance position generated by the input current. (8) the cam is set on the DA surface and operates positively while (16) the oscillating actuator shaft rotates in a clockwise direction when the input signal is increased. (2) The gain suppression spring is for direct feedback of the motion of (7) the exhaust valve to (4) the counter weight to increase the stability of the loop. The zero point should be adjusted by change of (3) the zero adjustment spring tension.






Series IP8


Principle of Operation

IP8001/Lever type

When the input current increases, the electrical current inside (12) the torque motor coil will change through (8) the plate's input process, operation process and output process, and (13) the armature will oscillate, with (11) the plate spring as its base. As a result, the clearance between (6) the nozzle and (5) the flapper will increase, and the nozzle back pressure will decrease. Consequently, (7) the exhaust valve of (1) the pilot valve moves to the right, the output pressure of OUT1 increases and causes (15) the diaphragm valve to move. The motion of (15) the diaphragm valve is transmitted to the displacement output process of (8) the board through (14) the feedback lever, (10) the feedback shaft and (9) angle sensor, and the calculated output position will match the input current.


Single action positive operation






IP8101/Rotary type

When the input current increases, the electrical current inside (12) the torque motor coil will change through (8) the plate's input process. operation process and output process, and (13) the armature will oscillate, with (11) the plate spring as its base. As a result, the clearance between (6) the nozzle and (5) the flapper will increase, and the nozzle back pressure will decrease. Consequently, (7) the exhaust valve of (1) the pilot valve moves to the right, the output pressure of OUT1 increases and causes the output pressure of OUT2 to decrease, causing (14) the oscillating actuator to move. The motion of (14) the oscillating actuator is transmitted to the fork lever-type fitting, (10) the feedback shaft (9) angle sensor, and the displacement output process of (8) the board, and output position will match the input current.









Series IP8□


Dimensions/IP8000 (Lever type)

IP8000-0□0 (Without terminal box)



IP8000-0□1 (With terminal box)






SMC

Series IP8

Dimensions/IP8001 (Lever type) IP8001-_{0□3} OUT2.1/4 (Rc, NPT, G) 110 With plug Α OUT1.1/4 (Rc, NPT, G) 192 SUP.1/4 (Rc, NPT, G) 198 40 110 43 23.5 35 58 23.5 147 ISMC Smart Positioner IP8001 125 At accessory "E": 110 At accessory "F": 110 (e) 150 125 1/2 (G, NPT), M20 At accessory "E": 195 At accessory "F": 275 4 x M8 x 1.25 depth 12 ≈194 Electric conduit Female thread for rear mounting With optional resin cable clamp ¹2 x M8 x 1.25 depth 12 Applicable cable O. D. ø7 to ø9: P368010-26 Female thread for side mounting Applicable cable O. D. ø9.1 to ø11: P368010-27 2 46 \Box -IP8001- $_{0\Box 4}^{0\Box 2}$ -W OUT2.1/4 (Rc, NPT, G) 110 With plug OUT1.1/4 (Rc, NPT, G) Α 192 SUP.1/4 (Rc, NPT, G) 198 40 110 43 35 58 109 Smart Positioner 147 125 At accessory "E": 110 At accessory "F": 110 (3) 5 150 At accessory "E": 195 At accessory "F": 275 125 4 x M8 x 1.25 depth 12 ≈229 Female thread for rear mounting /2 x M8 x 1.25 depth 12 Female thread for side mounting 2 x 1/2 (G, NPT), M20 Electric conduit 2 Note) The accessory body cover for LCD with viewing pane can be selected irrespective of specifications. Resin cable gland 46 Applicable cable O. D. ø6 to ø12

SMC

(Only supplied when the M20 is selected for intrinsically safe explosion proof products)



Electro-Pneumatic Positioner (Lever type/Rotary type)

Made to Order


Please contact SMC for detailed dimensions, specifications, and lead times.



1 Exterior Covering Enclosure: JISF8007 IP66 (Conforms to IEC60529)


* Same as the standard, other than the IP66 compliant protective cover.

How to Order IP8000/Lever type



Note 1) If two or more accessories are required, the part numbers should be given in alphabetical order. Note 2) If 1 is selected for Construction, M, N, 2, 3, 5, 6 cannot be selected for Connection.


IP8100/Rotary type



Note 1) If two or more accessories are required, the part numbers should be given in alphabetical order. Note 2) Symbol J/JR is with terminal box, non-explosion proof specification. Select 1 for Construction. Note 3) If 1 is selected for Construction, M, N, 2, 3, 5, 6 cannot be selected for Connection.



Dimensions




SMC

2 Exterior Covering Enclosure: JISF8007 IP66 (Conforms to IEC60529)


* Same as the standard, other than the IP66 compliant protective cover.

How to Order IP8001/Lever type



Note 1) If two or more accessories are required, the part numbers should be given in alphabetical order. Note 2) If a connecting port is $M20 \times 1.5$, a blue cable gland is included.

IP8101/Rotary type




Note 1) If two or more accessories are required, the part numbers should be given in alphabetical order. Note 2) If a connecting port is $M20 \times 1.5$, a blue cable gland is included.





Dimensions

IP8001-X405-P



IP8101-X405-P





* Shapes of parts other than the IP66 compliant protective cover are the same as the standard product. When the terminal box is not provided, refer to the external dimensions of the standard product for dimensions and shapes of the electric wiring parts.

IP66 compliant protective cover

Technical data

Explosion proof

1. TIIS explosion-proof construction

The electro-pneumatic positioner IP8000/8100 becomes explosion proof, as certified by TIIS, according to the model selected. The explosion-proof grade has the following approval: Exd $\rm IIBT5$.

Take extra care when handling the positioner as explosion-proof equipment

To use as Exd II BT5


A) Pressure-proof packing

As shown below in the chart, use "Cable gland" (Option).

B) Metal piping

Attach the sealant fitting bracket near the cable port.

(For details, refer to "The guideline on electric equipment explosion proof" published by the Technology Institution of Industrial Safety).



Cable gland with pressure proof packing (Option)

Description	Unit product no.	Applicable outside diameter	
Connector unit with	P368010-32	ø7.0 to ø10.0	
pressure proof packing	P368010-33	ø10.1 to ø12.0	

2. ATEX Intrinsically safe explosion-proof construction

Pneumatic positioners IP8000/8100 and IP8001/8101 Smart Positioners are ATEX compliant, intrinsically safe and explosion proof, as certified by KEMA, the accreditation body for explosion-proof products. Take extra care when handling these explosion-proof products.

In regards to explosion-proof grades,

The Pneumatic Positioner IP8 \square 00 meets ${1\!\!1}{2}{6\!\!1}{6\!\!1}{6\!\!1}$ Ex ib ${1\!\!1}{6\!\!1}{6\!\!1}{6\!\!1}$ CT5/T6, and


• Wiring

When using the positioner as an intrinsically safe explosion-proof product, always set up a barrier in a <u>safe environment</u>, and perform each positioner's wiring through the barrier. Simultaneously, use the provided cable gland (M20 x 1.5) as the extension for the lead wire. If a connecting port other than M20 x 1.5 is selected, the cable gland will not be provided, so use a cable gland with the same or greater explosion-proof grades than this positioner.

Barrier

Connect the barrier as shown in the diagram below. Moreover, the user must select a barrier that is suitable for each function, based on the ATEX intrinsically safe explosion-proof parameters (current circuit). For IP8001/8101 type smart positioners, use a linear resistant type barrier that is based on the explosion-proof parameters.

Barrier connection diagram




Moreover, at SMC, the barriers listed in the chart below are used to check operations. To purchase, please contact PEPPER + FUCHS Inc. (Germany).

Recommended barriers

	Manu- Model		Note	Applicable model		
	facturer	acturer		IP8□00-X14	52-IP8□01	
For input signal (non HART transmission)		KFD2-CD-Ex1.32	_	0	0	
For input signal (for HART transmission)	DEDDEDI	KFD2-SCD-Ex1.LK KCD2-SCD-Ex1	_	_	0	
For analog output	+	KFD2-STC4-Ex1	_	_	0	
	FUCHS (Germany)	KFD2-SOT2-Ex2	Transistor Output passive type	_	0	
For alarm output		KFD2-ST2-Ex2	T2-Ex2 Transistor Output passive type		0	
		KFD2-SR2-Ex2.W	Relay output	_	0	

HART transmission

With smart positioners IP8001/8101, the user can operate the positioner using buttons and change parameter settings by viewing the LCD display (shown the right). Furthermore, depending on the model selected, the same button operation and parameter settings, and monitoring is possible from a remote location via HART transmission.



The table below lists an example of applications that are compatible with smart positioner IP8001/8101. Application selection must be made by the user. Please contact Emerson Process Management for further details.

HART transmission compatible application

Product name Note)	Manufacturer
AMS™ Suite : Intelligent Device Manager®	Emerson Process
375 Field Communicator	Management (US)

Note) AMS™ Suite: Intelligent Device Manager® is a registered trademark of Emerson Electric Co.



 \triangle

Series IP8

Electro-Pneumatic Positioner/Smart Positioner Specific Product Precautions 1

Be sure to read this before handling.

Operation

⚠ Warning

- 1. Do not operate the positioner outside the specified range as this may cause problems. (Refer to the specifications.)
- Design the system to include a safety circuit to avoid the risk of danger should the positioner suffer failure.
- 3. Be sure that exterior lead-in wiring to the terminal box is based on the guidelines for explosion-protection of manufactory electric equipment when being used as a flame proof, explosion proof construction.
- 4. Do not remove terminal cover in a hazardous location while the power is on.
- 5. Covers for the terminal and body should be in place while operating.
- 6. When using as an intrinsically safe explosion-proof product, do not wire in a hazardous location while the power is on.

⚠ Caution

- 1. Do not touch the actuator or valve's oscillating section when supply pressure has been added, as this is dangerous.
- 2. Make sure fingers do not get caught when mounting and aligning the cam.

Cut off the pressure supply and always release the compressed air inside the positioner and actuator before performing this work.

3. Always use with the body cover unit mounted.

Moreover, the positioner may not meet degrees of protection IP65 depending on the body cover mounting conditions. In order to meet degrees of protection IP65, tighten threads using the proper tightening torques (2.8 to 3.0 N·m).

- 4. Always flush the pipe's insides before piping to ensure foreign objects such as machining chips do not enter the positioner.
- 5. The actuator opening may become unstable when using the booster relay.
- 6. Always use a ground connection to prevent noise from the input current and to prevent damage because of static electricity.
- 7. Use the pressure reading on the supplied pressure gauge as an indication.
- 8. The supplied pressure gauge's needle will malfunction if the pressure supply to the internal mechanism or positioner freezes.

Ensure that the pressure gauge's internal parts do not freeze if using the pressure gauge in an operating environment with an ambient temperature of less than 0°C.

This positioner performs the fixed position control.

Avoid turning ON or OFF the input signal highly frequently.

For Users

⚠ Caution

1. Assemble, operate and maintain the positioners after reading the operation manual thoroughly and understanding the content.

Handling

⚠ Caution

- 1. Avoid excessive vibration or impact to the positioner body and any excessive force to the armature, as these actions may cause damage to the product. Handle carefully while transporting and operating.
- 2. If being used in a place where vibration occurs, using a binding band is recommended to prevent broken wires because of the vibration.
- 3. When exposed to possible moisture invasion, please take the necessary measures. For example, if the positioner is left on-site for long periods, a plug should be put in the piping port and a body cover unit fitted to avoid water penetration.

Take measures to avoid dew condensation inside the positioner if exposed to high temperature and humidity. Take enough measures against condensation especially when packing for export.

4. Keep magnetic field off the positioner, as this affects its characteristics.

Air Supply

⚠ Caution

- 1. Use only dehumidified and dust extracted clean compressed air as the air supply.
- 2. Use only dehumidified and dust-extracted clean compressed clean air as the positioner contains extra-fine orifices such as restrictor and nozzle. Do not use a lubricator.
- 3. Do not use compressed air containing chemicals, organic solvents, salinity or corrosive gases, as this may cause malfunction.
- 4. When operating below the freezing point, protect the positioner from freezing.

\triangle

Series IP8

Electro-Pneumatic Positioner/Smart Positioner Specific Product Precautions 2

Be sure to read this before handling.

Operating Environment

⚠ Caution

- Do not operate in locations with an atmosphere of corrosive gases, chemicals, sea water, or where these substances will adhere to the regulator.
- Do not operate out of the indicated operation temperature range as this may cause damage to electronic parts and seal materials to deteriorate.
- 3. Do not operate in locations where excessive vibration or impact occurs.
- 4. If the body cover is being installed in a place where the body cover is exposed to direct sunlight, the use of a standard body cover without the LCD window is recommended.

Maintenance

Marning

1. After installation, repair or disassembly, connect compressed air and conduct tests to confirm appropriate function and leakage.

Do not use the positioner when noise from the bleeder sounds louder compared with the initial state, or when it does not operate normally. If these occur, check immediately if assembled and mounted correctly.

Never modify electrical construction to maintain explosionproof construction.

∧ Caution

1. Confirm whether the compressed air is clean.

Dust, oil, or moisture mixed within the equipment may result in malfunction and positioner problems. Perform periodic inspection of the air preparation equipment to ensure clean air is always supplied.

- Improper handling of compressed air is dangerous. Not only observing the product specifications, but also replacement of elements and other maintenance activities should be conducted by personnel having sufficient knowledge and experience pertaining to instrumentation equipment.
- 3. Perform annual inspections of the positioner.

Replace badly damaged seals and units such as diaphragm and O-ring during the inspection.

When used in tough environmental and/or service conditions such as seaside locations, replacements should be undertaken more frequently.

Maintenance

⚠ Caution

- 4. When performing inspections, demounting the positioner, or replacing the elements with the positioner still in its mounted position, first, stop the compressed air, then exhaust the residual pressure before undertaking operation.
- 5. Should the restrictor become clogged with carbon particles, etc., demount automatic/manual change-over screw (with built-in restrictor) and clean it using a Ø0.2 wire.
 - Stop the compressed air and remove the screw to switch the pilot valve off before replacing the restrictor.
- 6. Apply just a small amount of grease set by SMC to the sliding parts (O-ring and exhaust valve) when disassembling a pilot valve unit. Replacing the valve unit every three years is recommended.
- 7. Check for air leakage from pipes that pass compressed air and connecting parts.

Air leakage from air piping results in reduced operational performance and a decline of characteristics, etc.

It is structurally necessary for air to be released from the bleeder, it is not abnormal as long as the air consumption is within the specified range.

Pneumatic-Pneumatic Positioner (Lever type/Rotary type)

Series IP5000/5100


• JIS F8007 IP55

• Fulfilling options: Opening indicator (IP5100), Built-in bypass (SIG-OUT1) (IP5000), Built-in equalizing valve (OUT1-OUT2) (IP5100)

How to Order

Rc (Standard)

NPT



4	Α	CC	ess	ori	ies	Note	1)
---	---	----	-----	-----	-----	------	----

	• Accessories Note 1)				
	Nil	None (Standard)	With standard lever (10 to 85 mm stroke) for IP5000		
Α	ø0.7 Output restriction with pilot valve	Common to IP5000 and IP5100 small capacity			
	В	ø1.0 Output restriction with pilot valve	actuators		
	С	Fork lever-type fitting M	Only for IP5100		
	D	Fork lever-type fitting S			
	E	For stroke 35 to 100 mm with lever unit	Only for IP5000 Note 2)		
	F	For stroke 50 to 140 mm with lever unit	Offity for 1F5000 (1886 E)		

Note 1) If two or more accessories are required, the part numbers should be given in alphabetical order. Ex.) IP5000-010-AD Note 2) For "E" and "F", standard lever is not provided.

Specifications

Nil

Type	IP5000		IP5100		
, ,	Lever type lever feedback		Rotary type cam feedback		
Item	Single action	Double action	Single action	Double action	
Supply pressure	0.14 to 0.7 MPa				
Input pressure	0.02 to 0.1 MPa				
Standard stroke	10 to 85 mm		60° to 100°		
Sensitivity	Within 0.1% F.S.		Within 0.5% F.S.		
Linearity	Within ±1% F.S.	Within ±2% F.S.			
Hysteresis	Within 0.75% F.S.	n 0.75% F.S. Within 1% F.S.			
Repeatability	Within ±0.5% F.S.				
Air consumption	5 L/min (ANR) or less (SUP = 0.14 MPa)Note)		11 L/min (ANR) or less (SUP = 0.4 MPa) ^{Note)}		
Output flow rate	80 L/min (ANR) or more (SUP = 0.14 MPa)Note) 200 L/min (ANR) or more (SUP = 0.4 MPa)		re (SUP = 0.4 MPa)Note)		
Ambient and fluid temperature	-20°C to 80°C (Standard)				
Coefficient of temperature	Within 0.1% F.S./°C				
Air connection port	Rc1/4 (Standard)				
Main component parts	Aluminum die-cast, Stainless steel, Brass, Nitrile rubber				
Weight	Approx. 1.4 kg		Approx. 1.2 kg		
Dimensions	118 x 102 x 86 (Body)		118 x 92 x 77.5 (Body)		

Note) Standard air temperature: 20°C (293 K), Absolute pressure: 760 mmHg (101.3 kPa), Relative humidity: 65%

Replacement Parts

neplacement rants				
Part no.	Description	Note		
P378010-10	Pilot valve unit	For IP5000		
P378020-11	Pilot valve unit	For IP5100		
P368010-24	Fork lever assembly M	For IP5100 (Accessory: C)		
P368010-25	Fork lever assembly S	For IP5100 (Accessory: D)		
P378010-11	Feedback lever	For IP5000/10 to 85 mm (Accessory: Nil)		
P378010-12	Feedback lever	For IP5000/35 to 100 mm (Accessory: E)		
P378010-13	Feedback lever	For IP5000/50 to 140 mm (Accessory: F)		

Precautions

- 1. Avoid impact to positioner while transporting and handling.
- 2. Operate within specified temperature range to prevent deterioration of seals.
- 3. Attach a body cover to the positioner when it is in use or left in the field in order to avoid rain water.
- 4. Take measures to avoid dew condensation if the positioner is exposed to high temperature and humidity during transportation or storage or when it is left on the site.
- 5. The zero point is subject to the mounting position. Adjust zero point after installation on the site.



Series IP5000/5100

Principle of Operation


IP5000 type

When the input pressure applied to the SIG port of the positioner increases, bellows ① press balance lever ② to the left. As this movement moves flapper ④ to the left through connecting spring ③, the gap between nozzle ⑤ and flapper ④ widens, and the nozzle back pressure of pilot valve ⑥ drops. As a result, the pressure balance in the constant pressure chamber is broken, and exhaust valve ③ presses inlet valve B ⑭ to the right, thus opening inlet port B. Then, output pressure OUT1 rises, and driven diaphragm ⑦ moves downward.

The movement of diaphragm valve ⑦ deflects feedback arm ① to the right through feedback lever ⑧, transmission lever ⑨, and roller ①. Such deflection increases the tension of feedback spring ⑫ and acts on balance lever ②.

Since driven diaphragm ${\mathfrak D}$ moves until the tensile force of feedback spring ${\mathfrak D}$ and the force generated by bellows ${\mathfrak D}$ balance, it is always set in the position proportional to the input pressure. When the signal air pressure decreases, the operation is reversed.

IP5000 principle of operation




IP5100 type

When the input pressure applied to the SIG port of the positioner increases, bellows ① press balance lever ② to the left. As this movement moves flapper ④ to the left through connecting spring ③, the gap between nozzle ⑤ and flapper ④ widens, and the nozzle back pressure of pilot valve ⑥ drops. As a result, the pressure balance in the constant pressure chamber is broken, and exhaust valve ④ presses inlet valve B ⑤ to the right. Then, inlet port B opens, and output pressure OUT1 increases.

In the meantime, the movement of exhaust valve ⁽⁴⁾ to the right opens exhaust port A, and output pressure OUT2 decreases. Therefore, pressure difference is generated between pressure chamber 1 and pressure chamber 2 of oscillating actuator ⁽⁷⁾, and actuator shaft ⁽⁸⁾ turns in the direction of the arrow. The movement of actuator shaft ⁽⁸⁾ deflects feedback arm ⁽¹⁾ to the right through feedback shaft ⁽⁹⁾, cam ⁽¹⁾, and bearing ⁽¹⁾. Such deflection increases the tension of feedback spring ⁽³⁾ and acts on balance lever ⁽²⁾.

Since oscillating actuator $\widehat{\mathcal{D}}$ moves until the tensile force of feedback spring $\widehat{\mathbb{G}}$ and the force generated by bellows $\widehat{\mathbb{O}}$ balance, it is always set in the position proportional to the input pressure. When the signal air pressure decreases, the operation is reversed.


IP5100 principle of operation






Dimensions

IP5000 type (Lever type lever feedback)




IP5100 type (Rotary type cam feedback)



SMC

Cylinder Positioner Series IP200

- Servo-mechanism allows precise and stable position control of cylinders.
- Can be used as a cylinder position control unit for general industrial machines.



Specifications (No load)

Supply pressure	0.3 to 0.7 MPa
Input pressure	0.02 to 0.1 MPa
Applicable bore size	ø50 or more
Applicable stroke	25 to 300 mm or less
Sensitivity	Within 0.5% F.S.
Linearity	Within ±2% F.S.
Hysteresis	Within 1% F.S.
Repeatability	Within ±1% F.S.
Air consumption*	18 L/min (ANR) or less (SUP = 0.5 MPa)
Influence by change in supply pressure	Within 1% F.S./0.05 MPa
Ambient and fluid temperature	−5°C to 60°C
Port size	Rc1/4 (Gauge port Rc1/8)
Weight	Approx. 700 g


^{*} Air consumption is due to exhaust from nozzle.


Replacement Parts


Part no.	Description	Note
IP200-02	Pilot valve unit	
39020-23	Seal kit	Ambient temperature: Standard (-5° to 60°)


Construction/Principle of Operation


When signal pressure enters input chamber ①, the input diaphragm ③ is deflected left. Clearance of the nozzle ⑥ is reduced causing higher back pressure at diaphragm A ②. This diaphragm A ② has larger area than diaphragm B ⑧ resulting in movement of the spool to the left. Supply pressure then flows to OUT1 ① and partial exhaust from OUT2 takes place resulting in cylinder rod ⑤ movement to the right. The movement is linked via connecting rod ④ and feedback spring ② to the input diaphragm ③ balancing the higher pressure. When this occurs nozzle ⑥ clearance increases allowing centralizing of the spool ⑨ to take place. This holds the piston rod in the new position. Input signal increase results in proportional movement of the piston rod.











⚠ Precautions

Caution

⚠ Caution

- 1. Positioner has a restrictor and a nozzle which has fine paths in it. Therefore, use clean air which is dehydrated and filtered, and also avoid employing a lubricator which causes malfunction.
- 2. Be sure to flush the piping to prevent foreign matter from entering the positioner before connecting them.

Pneumatic Instrumentation Equipment

Regulators



Filter Regulator/IW	Page 38
Filter Regulator/1301	Page 42
Filter Regulator for Low Temperature Environment (-30 to 6	0°C)/
High Temperature Environment (-5 to 80°C)/	
AW-X430/-X440 ·····	Page 45
Filter Regulator: Stainless Steel 316 and	
Special Temperature Environment (-40°C) Specifications	s/
AW30/40-X2622	Page 47
Precision Regulator/IR	Page 51




Filter Regulator Series IW


• Two types are available: adjustable set pressure type and fixed set pressure type.

• Low/High temperature and external parts copper-free types can be selected.

• Pressure gauge connecting direction: 2 directions (Front/Back)

• Weight: 0.66 kg (Adjustable type), 0.58 kg (Fixed type)






			Cullix
	Low temperature (-30 to 60°C)	High temperature* (-10 to 100°C)	External parts copper-free
Nil	_	_	_
T	_	•	_
L	•	_	_
S	_	_	•
ST	_	•	•
SL	•	_	•


^{*} With pressure gauge type: Max. 80°C.


Standard Specifications


Model	IW212 IW213 IW215			IW222
Model	Adjustable type (Basic)			Fixed type
Maximum supply pressure		Max. 1.0 MPa		0.3 to 1.0 MPa
Set pressure	0.02 to 0.2 MPa	0.02 to 0.3 MPa	0.02 to 0.5 MPa	0.14 MPa
Air consumption (At maximum set pressure)		0.5 L/min (ANR) or less		
Ambient and fluid temperature		−10 to 60°C (No freezing)	
Filtration accuracy		5 μ	m	
Port size	Rc1/4			
Pressure gauge port	Rc1/4 (2 locations)			
Weight		0.58 kg		

Flow-rate Characteristics (Representative values)













Pressure Characteristics (Representative values)











Principle of Operation



Air flow from the inlet passes through filter (sintered metal) 5 where solids are removed. When handle 1 is adjusted downwards, adjusting spring ② is compressed. The inlet valve 4 is opened allowing air flow to the outlet. Air outlet pressure balances against diaphragm 3 and adjusting spring 2. When the outlet pressure is higher than the set pressure, the inlet valve 4 is closed and exhaust of the excess outlet pressure takes place through the adjusting spring cover bleed. This ensures constant outlet pressure is maintained.

Construction



Component Parts


No.	Description	Material	Note	
1	Body assembly	Aluminum die-casted/Aluminum	Silver color	
2	Bonnet Aluminum die-casted/Brass		Silver color	
3	Bowl assembly Aluminum die-casted/Brass		Silver color	
4	Handle	ABS/Stainless steel	_	

Replacement Parts

op	placement i are							
No.	Description	Material	Part no.					
5	Diaphragm assembly	Aluminum die-casted/Brass/NBR	P218010-1					
6	Element	Bronze	1301111-5B					
7	Seal	NBR	1301510					
8	Filter disk assembly	Brass/NBR	P218010-16					
9	O-ring	NBR	AS568-228					
10	O-ring	NBR	JISB2401 P4					

Series IW

Dimensions




42

Filter Regulator Series 1301

- External main parts: Stainless steel type is available.
- Low temperature/High temperature type is available. (Made-to-Order products of Series AW on page 45)

How to Order




1202	0.02 to 0.29 MPa				
2502	0.02 to 0.49 MPa				
902 * 0.02 to 0.2 MPa					
* External main parts are made					

of stainless steel. For details, refer to page 43.


Standard Specifications

Model		Basic type		External main parts: Stainless steel	
	1301-002	1301-1202	1301-2502	1301-902	
Maximum supply pressure		Max. 1	.0 MPa		
Set pressure	0.02 to 0.2 MPa	0.02 to 0.29 MPa	0.02 to 0.49 MPa	0.02 to 0.2 MPa	
Ambient and fluid temperature		−5 to 60°C (No freezing)		
Filtration accuracy		5 µ	ım		
Port size	Rc1/4				
Pressure gauge port	Rc1/8 (1 location)				
Weight	1.07 kg				

Flow-rate Characteristics (Representative values)




Pressure Characteristics (Representative values)



Principle of Operation


1301



Air flow from the inlet passes through filter (sintered metal) ⑤ where solids are removed. When handle ① is adjusted downwards, adjusting spring ② is compressed. The inlet valve ④ is opened allowing air flow to the outlet. Air outlet pressure balances against diaphragm ③ and adjusting spring ②. When the outlet pressure is higher than the set pressure, the inlet valve ④ is closed and exhaust of the excess outlet pressure takes place through the adjusting spring cover bleed. This ensures constant outlet pressure is maintained.

Construction

1301




Component Parts


		Material				
No.	Description	Basic type			External main parts: Stainless steel	Note
		1301-002	1301-1202	1301-2502	1301-902	
1	Decompression chamber		Zinc die-casted			Silver color
2	Bonnet		Zinc die-casted			Silver color
3	Handle	ABS/Brass			ABS/Stainless steel	_
4	Lock nut	Brass			Stainless steel	_
5	Round head Phillips screw		Brass		Stainless steel	_


Replacement Parts

			Part no.			
No.	Description	Material	Basic type			External main parts: Stainless steel
			1301-002	1301-1202	1301-2502	1301-902
6	Pilot valve	Stainless steel/NBR		1301207#1		1301207#1
7	Element	Bronze	1301111-5B		1301111-5B	
8	Diaphragm assembly	Weather resistant NBR/ Brass/ADC	13014A		13014A	
9	Bowl seal	NBR	130124		130124	
	Bowl socombly	ZDC/Brass	130191A		_	
10	Bowl assembly	ZDC/Stainless steel	_		130191A-S	









Filter Regulator AW30 to AW60 **Made to Order**



Please contact SMC for detailed dimensions, specifications, and lead times.

Special Temperature Environment


Special materials are used in the manufacturing of seals and resin parts to allow them to withstand various temperature conditions in cold or tropical (hot) climates.

Specifications

Made-to-Order part no.		-X430	-X440	
Environment		Low temperature	High temperature	
Ambient temperature (°C)		-30 to 60	-5 to 80	
Fluid tem	perature (°C)	-5 to 60 (with no freezing)		
Material	Rubber parts	Special NBR	FKM	
Main parts		Metal (Aluminum die-cast, etc.)		
Nominal	filtration rating	5 μm		

Applicable Model

Model	Model AW30		AW40-06	AW60
Port size	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1



X440 High temperature

AW30-03G-2-X440

- Option/Semi-standard: Select one each for a to g.
- · Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.

Example) AW30-03BG-2N-X430

							0	
			Symbol	Description		Body size		
				30	40	60		
		N		Nil	Rc	•	•	•
2	2 Thread type		read type	N	NPT	•	•	•
			F	G	•	•	•	
				+				
				02	1/4	•	•	_
				03	3/8	•	•	_
3		- 1	Port size	04	1/2	_	•	_
				06	3/4	_	•	•
				10	1	_	_	•
				+				
				Nil	Without mounting option	•	•	•
	Note 1)	а	a Mounting	B Note 2)	With bracket	•	•	•
	<u>i</u> j			Н	With set nut (for panel fitting)	•	•	_
	Option	+						
		h	b Pressure gauge	Nil	Without pressure gauge	•	•	•
			Pressure gauge	G Note 3)	Round type pressure gauge (without limit indicator)	•	•	•
_				+				
6		В	owl Note 4)	2	Metal bowl	•	•	•
				+				
		c Set pressure	Nil	0.05 to 0.85 MPa setting	•	•	•	
		Ŭ	Cot procedio	1 Note 5)	0.02 to 0.2 MPa setting	•	•	•
		+						
		d Drain port		Nil	With drain cock	•	•	•
	5	_		J Note 6)	Drain guide 1/4			•
	Semi-standard		1	+	T =			
6	ga	е	Exhaust mechanism	Nil	Relieving type	•	•	•
	 	Non-relieving type		•	•	•		
	Sen		1	+			_	
	0)	f	Flow direction	Nil	Flow direction: Left to right	•	•	•
				R	Flow direction: Right to left	•	•	•
					[N			
		g	Pressure unit	Nil Z Note 7)	Name plate, caution plate for bowl, and pressure gauge in imperial units: MPa	○ Nete 0\	O Note 0)	O Nete 0)
		Ū		Z Note /)	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F	O Note 8)	O Note 8)	O Note 8)

Note 1) Option B, G, H are not assembled and supplied loose at the time of shipment.

Note 2) Assembly of a bracket and set nuts (AW30 to AW40) Including 2 mounting screws for the AW60

Note 3) Mounting thread for pressure gauge: 1/8 for the AW30, 1/4 for the AW40 and AW60. Pressure gauge type: G43


Note 4) Only metal bowl 2 is available.


Note 5) The only difference from the standard specifications is the adjusting spring for the regulator. It does not restrict the setting of 0.2 MPa or more. When the pressure gauge is attached, a 0.2 MPa pressure gauge will be fitted.

Note 6) Without a valve function
Note 7) For thread type: NPT. This product is for overseas use only according to the new Measurement Law. (The SI unit type is provided for use in Japan.) Note 8) O: For thread type: NPT only





AW30-X430, -X440





Panel fitting dimensions





Filter Regulator


Stainless Steel 316 and Special Temperature Environment (-40°C) Specifications

AW30/40-X2622

- External parts material: Stainless steel 316
- Ambient and fluid temperature: -40 to 80°C
- NACE International Standards compliant

The JIS component standards of the external parts and the component measurement results of the certificate for materials are within the ANSI/NACE standards.

How to Order



- Option/Semi-standard: Select one each for a to d.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.

 Example) AW30-03C-2R-X2622A

		Symbol	Description	Body 30	
		Nil	Rc	•	•
2	Thread type	N	NPT	•	•
		F	G	•	•
		+			
		02	1/4		•
8	Port size	03	3/8		•
U	FOIT SIZE	04	1/2	_	•
		06	3/4	_	•
		+			
4	Option a Float type	Nil	Without option		•
U	i auto drain	C Note 1)	Float type auto drain (N.C.)		•
		+			
			• • • • •		

	<u> </u>								
		b	Bowl	2 Note 2)	Metal bowl	•	•		
6	Semi-standard								
U	Semi-standard	C	Flow direction	Elementine ettere	Class diversion	Nil	Flow direction: Left to right	•	•
				R	Flow direction: Right to left	•	•		
				+					
			_	Nil	Without option	•	•		
6	Option	d	Pressure	Α	Round type pressure gauge (without limit indicator)	•	•		
U	ii	a	gauge Note 3) Bracket	В	With bracket		•		
			Diacket	С	Round type pressure gauge (without limit indicator), With bracket	•	•		

Note 1) When the float type auto drain is selected, the fluid temperature range is -5 to 60°C (with no freezing), and the maximum operating pressure is 1.0 MPa. Take measures if the fluid temperature is likely to be out of the specified range due to the ambient temperature.

Note 3) The pressure gauge is shipped together, but not assembled. AW30: G43-10-□01-X3 or AW40: G43-10-□02-X3 is included.

Specifications

Fluid	Air		
Ambient and fluid temperature	−40 to 80°C (with no freezing)		
Proof pressure	3.0 MPa		
Maximum operating pressure	2.0 MPa		
Set pressure range	0.05 to 0.85 MPa		
Nominal filtration rating	5 μm		
Drain capacity (cm ³)	AW30: 20, AW40: 80		
Construction	Relieving type		
Weight (kg)	AW30: 1.19, AW40: 3.40		

Applicable Model


Model	AW30	AW40
Port size	1/4, 3/8	1/4, 3/8, 1/2, 3/4




Note 2) Only metal bowl is available.


Flow-rate Characteristics (Representative values)

Condition: Inlet pressure 0.7 MPa






AW40-04-2-X2622




Pressure Characteristics (Representative values)

Conditions: Inlet pressure 0.7 MPa, Outlet pressure 0.2 MPa, Flow rate 20 L/min (ANR)

AW30-02-2-X2622





AW40-04-2-X2622



AW30/40-X2622

Construction







Component Parts

No.	Description	Material		
1	Body	SCS14A (Equivalent to Stainless steel 316)		
2	Bonnet	SCS14A (Equivalent to Stainless steel 316)		
3	Bowl	SCS14A (Equivalent to Stainless steel 316)		
4	Pressure adjustment screw	Stainless steel 316L		
5	Adjusting spring	Stainless steel 304		
6	Diaphragm	CR		
7	Deflector	PBT		
8	Valve	Stainless steel 316/Low-temperature NBR		
9	Valve guide	Stainless steel 316		
10	Element	Stainless steel 316L		
11	Drain cock	Stainless steel 316		
12	O-ring	Low-temperature NBR		
13	Bracket	Stainless steel 316		
14	Auto drain	POM/PBT/Foamed phenol/NBR etc.		
15	Drain guide	Stainless steel 316		







Model	т	Λ	R	_	n	F	F	G	н	J K	н л	М	N	N	Р	0	R	9	With au	to drain
Model	·	^	5			-		<u> </u>			'`				.	l ''	3	В	E	
AW30-X2622	1/4, 3/8	53	208	53	21.4	92	10	46	ø43	2	61.5	41	61	40	8	6.5	1/8	255	139.5	
AW40-X2622	1/4, 3/8, 1/2, 3/4	75	334	72	29.8	146	13	56	ø43	2.5	73	50	80	54	10.5	8.5	1/4	366	178	

Regulator

Regulator

Best Pneumatics

Precision Regulator *IR*



•Setting sensitivity: Within 0.2% F.S. •Repeatability: Within ±0.5% F.S.



Series	Port size	Set pressure (MPa)		
IR1000	1/8	0.005 to 0.2		
IR2000	1/4	0.01 to 0.4 0.01 to 0.8		
IR3000	1/4, 3/8, 1/2	0.01 to 0.2 0.01 to 0.4 0.01 to 0.8		

Pneumatic Instrumentation Equipment

Relays/Valves



D -	I
Re	เลง

Booster Relay/IL100	Page 53
---------------------	---------


Valves

Lock-Up Valve/ IL201/211/220	Page 56
	I due Ju

Booster Relay Series IL 100

 Used when the piping distance between instrumentation and operational area is long, or when operational area has large capacity.






Standard Specifications


Supply pressure	Max. 1.0 MPa
Input pressure	Max. 0.7 MPa
Output pressure	Max. 0.7 MPa
Pressure ratio	1:1
Air consumption	3 L/min (ANR) or less (OUT = 0.5 MPa)
Linearity	Within ±1%
Hysteresis	Within 1%
Ambient and fluid temperature	−5 to 60°C
Port size	1/4, 3/8
Weight	0.56 kg

Flow-rate Characteristics




Principle of Operation

IL100



Signal pressure enters the input chamber ① and diaphragm A ② and exerts a downward force on diaphragm B ③. When the force of the input chamber ① exceeds the force of diaphragm B ③, inner valve ⑥ is inseated allowing air flow out the secondary supply port. On signal pressure exhaust the supply valve closes and exhaust flow path ⑤ is opened to allow vent of the secondary air supply to atmosphere. Input and output ports are connected by a needle valve 4. Adjustment ensures that exact equalization occurs between the signal and output supply. The above function allows a low volume signal to provide high volume output with pressure ratio remaining (1:1) for signal to output.

Construction



Component Parts

	omponent rante										
No.	Description	Material	Note								
1	Valve	Aluminum alloy	Silver baking finish								
2	Cover	Aluminum alloy	Silver baking finish								
3	Throttle valve	Stainless steel									
4	Inner valve	Stainless steel									
5	Diaphragm assembly	Aluminum alloy/NBR/Resin	Chromated								
6	Diaphragm	NBR									
7	Valve spring	Stainless steel									
8	O-ring	NBR									
9	O-ring	NBR									


Replacement Parts


Model	Order no.	Contents
IL100	KT-IL100	Set of left nos. 5, 6, 7, 8, 9

Series IL100

Dimensions

IL100






Lock-Up Valve

Series IL201/211/220

 The lock-up valve is used if any air source or air supply piping line failure occurs in the air operated process control line.

Single acting, Double acting: Retains pressure at the operating area as emergency operation until the air source is recovered to its normal state.

3 Port: Changes the supply port if a trouble occurs.




Standard Specifications

Model	IL201	IL211	IL220			
Action	Single acting Double acting 3 Port					
Signal pressure	Max. 1.0 MPa Note 1)					
Set pressure range	0.14 to 0.7 MPa Note 1)					
Shut-off pneumatic circuit pressure	Max. 0.7 MPa					
Ambient and fluid temperature	−5 to 60°C					
Port size	Rc1/4					
Differential Note 2)	0.01 MPa					
Weight	0.45 kg 0.64 kg 0.7 kg					

Note 1) Provide a differential pressure of 0.1 MPa or more between the signal pressure and set pressure. If the differential pressure is small, the internal part is worn out due to the structure of this product and the bleed amount from the exhaust port increases, which may affect the characteristics.

Note 2) Pressure difference between lock activated and lock

Principle of Operation





The signal air pressure enters the upper diaphragm chamber 1 to generate a force. When this force is larger than the force generated by compressing the adjusting spring 3, the upper diaphragm 2 is pushed up, the exhaust port 4 is closed, and the signal air pressure enters the lower diaphragm chamber 5 and acts the lower diaphragm 6. This pushes down the piston (7) to open the valve.


IL201 and IL211 enter the status, in which the flow path between IN and OUT is opened, IL220 enters the status, in which the flow path between IN1 and OUT is opened. If the signal air pressure drops to a level below the set pressure for some reason, the upper diaphragm ② is pushed down, the pressure inside the lower diaphragm 5 is exhausted from the exhaust port 4, and the valve 8 is closed by the force of the spring 9. At this time, IN and OUT are shut down in IL201 and IL211. In IL220, IN1 and OUT are shut down, and the flow path between IN2 and OUT is opened. The set pressure is adjusted with the adjusting screw 10.

Series IL201/211/220

Construction







Component Parts


57


COII	iponeni Paris		
No.	Description	Material	Note
1	Body	Aluminum alloy	Silver baking finish
2	Pilot body	Aluminum alloy	Silver baking finish
3	Bonnet	Aluminum alloy	Silver baking finish
4	Adjusting screw	Stainless steel	
5	Piston	Brass	
6	Piston rod	Brass	
7	Diaphragm assembly	Aluminum alloy/Brass/NBR	Chromated
8	Diaphragm	NBR	
9	Piston valve	Brass/NBR	
10	Piston valve	Brass/NBR	
11	Valve	Brass/NBR	
12	Adjusting spring	Steel wire	Zinc chromated
13	Valve spring	Stainless steel	
14	Valve spring	Stainless steel	
15	Piston spring	Stainless steel	
16	O-ring	NBR	
17	O-ring	NBR	
18	O-ring	NBR	
19	O-ring	NBR	
20	O-ring	NBR	
21	O-ring	NBR	
22	O-ring	NBR	

Replacement Parts


Model	Order no.	Contents								
IL201	KT-IL201	Set of left nos. 7, 8, 9, 12, 13, 16, 17, 18, 19								
IL211	KT-IL211	Set of left nos. 7, 8, 9, 10, 12, 13, 16, 17, 18, 19								
IL220	KT-IL220	Set of left nos. 7, 8, 11, 12, 14, 15, 19, 20, 21, 22								


IL201







IL211





IL220





Pneumatic Instrumentation Equipment

Electro-Pneumatic Transducers



Electro-Pneumatic Transducer/IT600 Page 60

Electro-Pneumatic Transducer Series IT600


- The air pressure in proportion to the current signal can be output. Can be used as input pressure signal in combination with the pneumatic-pneumatic positioner.
- Wide output pressure range/0.02 to 0.6 MPa The maximum pressure can be set freely through the span adjustment.
- Fast response


The pilot valve capacity is large and the large flow can be obtained. Therefore, the response is excellent when operating the actuator directly or controlling the inner pressure of the tank with a large capacity.

- Independent electric unit/Explosion-proof (flameproof) construction The span adjustment, zero-point adjustment, and inspection maintenance can be performed with the body cover removed even in a hazardous place where the explosion or fire may occur.
- Easy span adjustment


As the span adjustment mechanism uses a vector mechanism, the span adjustment can be performed smoothly.

Output pressure setting range





How to Order



Pressure gauge*

0	None					
1	0.2 MPa					
2	0.3 MPa					
3	1 MPa					
4	0.4 MPa					
6	0.6 MPa					
*(SUP, OUT1)						

External wiring connection

Input current

0 4 to 20 mA DC

0	Flameproof threaded-joint metal conduit and normal joint not requiring explosion-proof design
1	Flameproof packing type cable gland

Seal type

J

0	None
1	Applicable cable O.D. 7 to 7.9 mm
2	Applicable cable O.D. 8 to 8.9 mm
3	Applicable cable O.D. 9 to 9.9 mm
4	Applicable cable O.D. 10 to 10.9 mm
5	Applicable cable O.D. 11 to 11.5 mm
6	A complete set of 5 types of flameproof packing

Specifications

Model	IT600	IT601					
Item	Low pressure	High pressure					
Input current	4 to 20 mA DC						
Input impedance	235 Ω (4 to 2	20 mA, 20°C)					
Supply air pressure	0.14 to 0.24 MPa	0.24 to 0.7 MPa					
Output pressure	0.02 to 0.1 MPa (Max. 0.2 MPa)	0.04 to 0.2 MPa (Max. 0.6 MPa)					
Linearity	Within ±1.0% F.S.						
Hysteresis	Within 0.75% F.S.						
Repeatability	Within ±0.5% F.S.						
Air consumption	7 L/min (ANR) (SUP = 0.14 MPa)	22 L/min (ANR) (SUP = 0.7 MPa)					
Ambient and fluid temperature	−10 to 60°C						
Air connection port	Rc1/4 female thread						
Electrical connection	Rc1/2 female thread						
Explosion-proof construction	Explosion-proof (flameproof) construction d2G4 (Certificate no. T28926)						
Material	Aluminum die-cast body						
Weight	3 kg						

Replacement Parts

None

Bracket

(2B pipe installation)

Hexagon wrench

(for tightening terminal cover)

Part no.	Description	Note		
P255010-1	Pilot valve unit	IT600		
P255010-19	Pilot valve unit	IT601		


Series IT600

Principle of Operation

When the input current increases, armature 1 in the torque motor will be subjected to a clockwise torque, pushing flapper lever 2 to the left. As a result, the clearance of nozzle flapper 3 will increase and the nozzle back pressure will decrease. This moves exhaust valve 0 of pilot valve 5 to the left, causing the output air pressure of OUT1 to increase.

The output pressure thus increased is passed through the path inside the pilot valve to pressure sensing bellows 6, where it is converted to the force. This force acts on vector mechanism 7 via lever 1. Because the force will balance the force


Block diagram illustrating operating principle




generated by means of the input current at lever fulcrum 1, the output air pressure proportional to the input current will be obtained.

Gain suppression spring \circledR functions to immediately feedback the movement of the exhaust valve to the flapper lever, thereby contributing to loop stability.

Zero point and span adjustments are performed by varying the tension force of zero adjusting spring (9) and the angle of the vector mechanism, respectively.



Dimensions



Pneumatic Instrumentation Equipment

Actuators



P Cylinder (Cylinder with Positioner)/CPA2	Page 63
CDS1	Page 63




P Cylinder (Cylinder with Positioner)

Series CPA2/CPS1

CPA2 Ø50, Ø63, Ø80, Ø100 CPS1 Ø125, Ø140, Ø160, Ø180, Ø200, Ø250, Ø300

- The cylinder positioning in proportion to the input signal (air pressure) is possible.
- Correction operation function: Returns to the initial setting position even when the position deviates due to load variations.

How to Order



Specifications

Item	Мо	del				
item	CPA2	CPS1				
Input pressure	0.02 to (0.1 MPa				
Supply pressure	0.3 to 0).7 MPa				
Linearity	Within ±	-2% F.S.				
Hysteresis	Within 1% F.S.					
Repeatability	Within ±1% F.S.					
Sensitivity	Within 0.5% F.S.					
Air consumption	18 L/min (ANR) or less (SUP = 0.5 MPa) Note 1)					
Ambient and fluid temperature	-5°C to 60°C (No freezing) 0°C to 60°C (No freezing)					
Coefficient of temperature	0.1% F.S./°C					
Stroke adjustment margin	Within 10% F.S.					
Applicable cylinder stroke	25 mm (Min.) to 300 mm (Max.)					
Air connection port	Rc1/4 female thread Note 2)					

Note 1) (ANR) indicates JIS B0120 standard air.


Note 2) Please contact SMC for connection ports other than the standard.

Construction/Principle of Operation

When input pressure enters input chamber 1, the input diaphragm 3 is deflected left. Clearance of the nozzle 6 is reduced causing higher back pressure at diaphragm A 7.

P Cylinder (Cylinder with Positioner) Series CPA2/CPS1

This diaphragm A ⑦ has larger area than diaphragm B ⑧ resulting in movement of the spool to the left. Supply pressure then flows to OUT1 ① and the air inside the cylinder is exhausted from OUT2, resulting in cylinder rod ⑤ movement to the right. The movement is linked via connecting rod ④ and feedback spring ② to the input diaphragm ③ balancing the higher pressure. When this occurs nozzle ⑥ clearance increases allowing centralizing of the spool ⑨ to take place. This holds the piston rod in the new position. Input signal increase results in proportional movement of the piston rod.








Series CPA2


Dimensions


Basic: CPA2B











With rod boot

Dimensions (mm)

Bore size A	_			~D	~D	~ D	~ D	øΕ	_	G	N	s	ММ	Without	rod boot			With roc	boot	
bore size	Α	□В	□C	ø D	ØE	-	G	'	3	IVIIVI	Н	ZZ	øe	f	h	e	ZZ			
50	35	70	52	20	40	10	31	30	90	M18 x 1.5	58	159	52	11.2	66		167			
63	35	85	64	20	40	10	31	31	98	M18 x 1.5	58	170	52	11.2	66	1/4	178			
80	40	102	78	25	52	14	41	37	116	M22 x 1.5	71	204	65	12.5	80	stroke	213			
100	40	116	92	30	52	14	41	40	126	M26 x 1.5	72	215	65	14	81		224			

Note 1) Use only dehumidified and dust extracted clean compressed air as the air supply.

Note 2) Install a cylinder so that the cylinder rod might not be twisted.


Note 3) Do not apply force to the protective cover of the feedback spring.


Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.


Note 5) Do not use a lubricator.

Note 6) Cylinder dimensions are the same as those of the CA2 series. For details, refer to **the WEB catalog** or the Best Pneumatics No. 2. Note 7) When using the cylinder outdoors, take measures to avoid wind and rain.

Axial foot: CPA2L







With rod boot

Dimensions


(mm)


Bore siz	e 🗆	,	□С		v	v	al D	LH	1.0	1.7	ıv	LY	Without	rod boot		W	ith rod boot	
Dore Siz		^		3	^	T	ø LD	LN	LS	LI	LA	Lĭ	Н	ZZ	f	h	e	ZZ
50	70	0	52	90	27	13	9	45	144	3.2	50	80	58	188	11.2	66		196
63	8	5	64	98	34	16	11.5	50	166	3.2	59	93	58	206	11.2	66	1/4	214
80	10	2	78	116	44	16	13.5	65	204	4.5	76	116	71	247	12.5	80	stroke	256
100	110	6	92	126	43	17	13.5	75	212	6	92	133	72	258	14	81		267

Note 1) Use only dehumidified and dust extracted clean compressed air as the air supply.

- Note 2) Install a cylinder so that the cylinder rod might not be twisted.
- Note 3) Do not apply force to the protective cover of the feedback spring.
- Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.
- Note 5) Do not use a lubricator.
- Note 6) Cylinder dimensions are the same as those of the CA2 series. For details, refer to the WEB catalog or the Best Pneumatics No. 2.
- Note 7) When using the cylinder outdoors, take measures to avoid wind and rain.

Rod flange: CPA2F





With rod boot

Dimensions

1	٠.						١
•	r	T	1	ľ	T	1	١

Bore size	В	□С		FV	ø FD	FT	FX	FY	FZ	Without	rod boot		٧	Vith rod boot	
Dore Size	В		S	FV	ØFD	FI	「^		FZ	Н	ZZ	f	h	e	ZZ
50	81	52	90	70	9	12	90	50	110	58	159	15	66		167
63	101	64	98	86	11.5	15	105	59	130	58	170	17.5	66	1/4	178
80	119	78	116	102	13.5	18	130	76	160	71	204	21.5	80	stroke	213
100	133	92	126	116	13.5	18	150	92	180	72	215	21.5	81		224


- Note 1) Use only dehumidified and dust extracted clean compressed air as the air supply.
- Note 2) Install a cylinder so that the cylinder rod might not be twisted.
- Note 3) Do not apply force to the protective cover of the feedback spring.
- Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.
- Note 5) Do not use a lubricator.
- Note 6) Cylinder dimensions are the same as those of the CA2 series. For details, refer to the WEB catalog or the Best Pneumatics No. 2.
- Note 7) When using the cylinder outdoors, take measures to avoid wind and rain.



Series CPA2

Dimensions

Head flange: CPA2G





bore size		⊔₿		ာ	FV	ØFD	Г		Fĭ		Н	ZZ	f	h	e	ZZ
50	81	70	52	90	70	9	12	90	50	110	58	160	11.2	66		168
63	101	85	64	98	86	11.5	15	105	59	130	58	171	11.2	66	1/4	179
80	119	102	78	116	102	13.5	18	130	76	160	71	205	12.5	80	stroke	214
100	133	116	92	126	116	13.5	18	150	92	180	72	216	14	81		225


Note 1) Use only dehumidified and dust extracted clean compressed air as the air supply.


- Note 2) Install a cylinder so that the cylinder rod might not be twisted.
- Note 3) Do not apply force to the protective cover of the feedback spring.
- Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.
- Note 5) Do not use a lubricator.
- Note 6) Cylinder dimensions are the same as those of the CA2 series. For details, refer to **the WEB catalog** or the Best Pneumatics No. 2.
- Note 7) When using the cylinder outdoors, take measures to avoid wind and rain.

Single clevis: CPA2C









With rod boot

Dimensions (mm)

Bore size	size L S U			Ø СD н10	СХ	Wit	hout rod I	boot			With rod boot		
Dore Size	-	3	"	ØС Б н10	CX	Н	Z	ZZ	f	h	e	Z	ZZ
50	35	90	19	12 ^{+0.070}	18.0-0.1	58	183	195	11.2	66		191	203
63	40	98	23	16 ^{+0.070}	25.0-0.1	58	196	212	11.2	66	1/4	204	220
80	48	116	28	20+0.084	31.5 ^{-0.1} _{-0.3}	71	235	255	12.5	80	stroke	244	264
100	58	126	36	25 ^{+0.084}	35.5 ^{-0.1} _{-0.3}	72	256	281	14	81		265	290

Note 1) Use only dehumidified and dust extracted clean compressed air as the air supply.

Note 2) Install a cylinder so that the cylinder rod might not be twisted.

Note 3) Do not apply force to the protective cover of the feedback spring.


Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.


Note 5) Do not use a lubricator.

Note 6) Cylinder dimensions are the same as those of the CA2 series. For details, refer to **the WEB catalog** or the Best Pneumatics No. 2.

Note 7) When using the cylinder outdoors, take measures to avoid wind and rain.

Double clevis: CPA2D





With rod boot

Dimensions

(mm)

Bore size				Ø СD н10	сх	CZ	øDd9	With	out rod	boot			With rod boot		
Dore Size		3	"	ØCDH10	CX		ØDU9	Н	Z	ZZ	f	h	e	Z	ZZ
50	35	90	19	12 ^{+0.070}	18.0 ^{+0.3}	38	12 ^{-0.050} _{-0.093}	58	183	195	11.2	66		191	203
63	40	98	23	16 ^{+0.070}	25.0 ^{+0.3} _{+0.1}	49	16 ^{-0.050} _{-0.093}	58	196	212	11.2	66	1/4	204	220
80	48	116	28	20+0.084	31.5 ^{+0.3} _{+0.1}	61	20-0.065	71	235	255	12.5	80	stroke	244	264
100	58	126	36	25 ^{+0.084}	35.5 ^{+0.3} _{+0.1}	64	25 ^{-0.065} _{-0.117}	72	256	281	14	81		265	290

Note 1) Use only dehumidified and dust extracted clean compressed air as the air supply.


- Note 2) Install a cylinder so that the cylinder rod might not be twisted.
- Note 3) Do not apply force to the protective cover of the feedback spring.
- Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.


Note 5) Do not use a lubricator.


Note 6) Cylinder dimensions are the same as those of the CA2 series. For details, refer to **the WEB catalog** or the Best Pneumatics No. 2.

Note 7) When using the cylinder outdoors, take measures to avoid wind and rain.

Center trunnion: CPA2T







Dimensions

(mm)

Bore size				Ø TD e8	тт	TV	TV	TZ	With	out rod	boot			With rod boot		
Dore Size	□B	□C	3	Ø I De8	''	05 74	12	Н	Z	ZZ	f	h	e	Z	ZZ	
50	70	52	90	15 ^{-0.032} -0.059	22	95	74	127	58	103	154	11.2	66		111	162
63	85	64	98	18 ^{-0.032} -0.059	28	110	90	148	58	107	162	11.2	66	1/4	115	170
 80	102	78	116	25 ^{-0.040} -0.073	34	140	110	192	71	129	194	12.5	80	stroke	138	203
100	116	92	126	25 ^{-0.040} -0.073	40	162	130	214	72	135	206	14	81		144	215

Note 1) Use only dehumidified and dust extracted clean compressed air as the air supply.


- Note 2) Install a cylinder so that the cylinder rod might not be twisted.
- Note 3) Do not apply force to the protective cover of the feedback spring.
- Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.
- Note 5) Do not use a lubricator.
- Note 6) Cylinder dimensions are the same as those of the CA2 series. For details, refer to the WEB catalog or the Best Pneumatics No. 2.
- Note 7) When using the cylinder outdoors, take measures to avoid wind and rain.




Series CPS1

Dimensions

Basic: CPS1B





Dimensions (mm)

Bore size	_	□В	□с	øD	øΕ	_	_	G MM N S	Witho	out rod boot			W	ith rod boot			
Dore Size	Α	⊔ b		שש	ØE	Г	G	IVIIVI	IN	3	Н	ZZ	øe	f	h	e	ZZ
125	50	145	115	36	90	43	52	M30 x 1.5	35	98	110	235	75	40	133		258
140	50	161	128	36	90	43	52	M30 x 1.5	35	98	110	235	75	40	133		258
160	56	182	144	40	90	43	59	M36 x 1.5	39	106	120	256.5	75	40	141	0.2 stroke	277.5
180	63	204	162	45	115	48	66	M40 x 1.5	39	111	135	281	85	45	153	Stroke	299
200	63	226	182	50	115	48	66	M45 x 1.5	39	111	135	281	90	45	153		299
250	71	277	225	60	140	60	77	M56 x 2.0	49	141	160	342.5	105	55	176	0.17	358.5
300	80	330	270	70	140	60	88	M64 x 2.0	49	146	175	372.5	115	55	190	stroke	387.5

Note 1) If the air is not for pneumatic instrumentation, install a mist separator on the supply pressure side.

Note 2) Install a cylinder so that the cylinder rod might not be twisted.

Note 3) Do not apply force to the protective cover of the feedback spring.

Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.


Note 5) Do not use a lubricator.


Note 6) Cylinder dimensions are the same as those of the CS1 series. For details, refer to the WEB catalog or the Best Pneumatics No. 2.


Note 7) When using the cylinder outdoors, take measures to avoid wind and rain.



Axial foot: CPS1L







Dimensions

(mm)	
---	----	---	--

Bore size	В	□c	_	s	v	v	LD	LH	LS	LT	LX	LY	Without	rod boot		Witl	n rod boot	
Dore Size	•		F	3	^	ľ	LD		LS	L	LA	Li	Н	ZZ	f	h	e	ZZ
125	145	115	43	98	45	20	19	85	188	8	100	157.5	110	273	40	133		296
140	161	128	43	98	45	30	19	100	188	9	112	180.5	110	283	40	133		306
160	182	144	43	106	50	25	19	106	206	9	118	197.0	120	301	40	141	0.2 stroke	322
180	204	162	48	111	60	30	24	125	231	10	132	227.0	135	336	45	153	Stroke	354
200	226	182	48	111	60	30	24	132	231	10	150	245.0	135	336	45	153		354
250	277	225	60	141	80	40	29	160	301	12	180	298.5	160	421	55	176	0.17	437
300	330	270	60	146	90	40	33	200	326	15	212	365.0	175	451	55	190	stroke	466

Note 1) If the air is not for pneumatic instrumentation, install a mist separator on the supply pressure side.

Note 2) Install a cylinder so that the cylinder rod might not be twisted.


Note 3) Do not apply force to the protective cover of the feedback spring.


Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.


Note 5) Do not use a lubricator.

Note 6) Cylinder dimensions are the same as those of the CS1 series. For details, refer to the WEB catalog or the Best Pneumatics No. 2.

Rod flange: CPS1F







Dimensions

- 1	m	n	٠١
١,	ш	ш	1,

Bore size	В	□С	S	FD	FT	FX	FY	FZ	Without rod boot		With rod boot			
Dore Size								FZ	Н	ZZ	f	h	e	ZZ
125	145	115	98	19	14	190	100	230	110	238	40	133	0.2 stroke	261
140	160	128	98	19	20	212	112	255	110	232	40	133		255
160	180	144	106	19	20	236	118	275	120	252	40	141		273
180	200	162	111	24	25	265	132	320	135	277	45	153		295
200	225	182	111	24	25	280	150	335	135	277	45	153		295
250	275	225	141	29	30	355	180	420	160	336	55	176	0.17	352
300	330	270	146	33	30	400	212	475	175	369	55	190	stroke	384

Note 1) If the air is not for pneumatic instrumentation, install a mist separator on the supply pressure side.

Note 2) Install a cylinder so that the cylinder rod might not be twisted.

Note 3) Do not apply force to the protective cover of the feedback spring. Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.

Note 5) Do not use a lubricator.

Note 6) Cylinder dimensions are the same as those of the CS1 series. For details, refer to the WEB catalog or the Best Pneumatics No. 2.


Note 7) When using the cylinder outdoors, take measures to avoid wind and rain.





Series CPS1

Dimensions

Head flange: CPS1G








Dimensions


(mm)


Bore size	В	□С	FD	FT	FX	FY	FZ	s	Without rod boot		With rod boot				
Dole Size									Н	ZZ	f	h	e	ZZ	
125	145	115	19	14	190	100	230	98	110	235	40	133		258	
140	160	128	19	20	212	112	255	98	110	235	40	133	0.2 stroke	258	
160	180	144	19	20	236	118	275	106	120	256.5	40	141		277.5	
180	200	162	24	25	265	132	320	111	135	281	45	153		299	
200	225	182	24	25	280	150	335	111	135	281	45	153		299	
250	275	225	29	30	355	180	420	141	160	342.5	55	176	0.17	358.5	
300	330	270	33	30	400	212	475	146	175	372.5	55	190	stroke	387.5	


- Note 1) If the air is not for pneumatic instrumentation, install a mist separator on the supply pressure side.
- Note 2) Install a cylinder so that the cylinder rod might not be twisted.
- Note 3) Do not apply force to the protective cover of the feedback spring.
- Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.
- Note 5) Do not use a lubricator.
- Note 6) Cylinder dimensions are the same as those of the CS1 series. For details, refer to **the WEB catalog** or the Best Pneumatics No. 2.
- Note 7) When using the cylinder outdoors, take measures to avoid wind and rain.

Single clevis: CPS1C









Dimensions

(mm)

Bore size	□В	□С	F	L	s	U	Ø CD н10	сх	Without rod boot			With rod boot				
Bole Size					3	U	ØCDH10		Н	Z	ZZ	f	h	e	Z	ZZ
125	145	115	43	65	98	35	25 ^{+0.084}	32 ^{-0.3}	110	273	302	40	133		296	325
140	161	128	43	75	98	40	28 ^{+0.084}	36 ^{-0.3}	110	283	315	40	133	0.2 stroke	306	338
160	182	144	43	80	106	45	32 ^{+0.100}	40_0.1	120	306	342	40	141		327	363
180	204	162	48	90	111	50	40 ^{+0.100}	50 ^{-0.3}	135	336	380	45	153		354	398
200	226	182	48	90	111	50	40 ^{+0.100}	50 ^{-0.3}	135	336	380	45	153		354	398
250	277	225	60	110	141	65	50 ^{+0.100}	63 ^{-0.3}	160	411	466	55	176	0.17	427	482
300	330	270	60	130	146	80	63 ^{+0.120}	80_0.1	175	451	519	55	190	stroke	466	534

Note 1) Use only dehumidified and dust extracted clean compressed air as the air supply.

Note 2) Install a cylinder so that the cylinder rod might not be twisted.

Note 3) Do not apply force to the protective cover of the feedback spring.

Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.

Note 5) Do not use a lubricator.

Note 6) Cylinder dimensions are the same as those of the CS1 series. For details, refer to the WEB catalog or the Best Pneumatics No. 2.


Note 7) When using the cylinder outdoors, take measures to avoid wind and rain.





Actuators

Dimensions

Double clevis: CPS1D







Dimensions

(mm)

Dava siza	□В]	_		٥		~CD	СТ	СХ	C7 ~D		CZ ØDd9		67 ~	C7 ~D		out rod	boot			With rod boot		
Bore size	□□□	□С	Г	-	ુ	U	Ø CD н10	CI	CX	CZ	CZ ØDd9	Н	Z	ZZ	f	h	e	Z	ZZ				
125	145	115	43	65	98	35	25 ^{+0.084}	17	32 ^{+0.3} _{+0.1}	$64^{-0}_{-0.2}$	25 ^{-0.065} -0.117	110	273	302	40	133		296	325				
140	161	128	43	75	98	40	28 ^{+0.084}	17	36 ^{+0.3} _{+0.1}	$72^{-0}_{-0.2}$	28 ^{-0.065} -0.117	110	283	315	40	133		306	338				
160	182	144	43	80	106	45	32 ^{+0.100}	20	40+0.3	$80^{-0}_{-0.2}$	$32^{-0.080}_{-0.142}$	120	306	342	40	141	0.2 stroke	327	363				
180	204	162	48	90	111	50	40 ^{+0.100}	23	50 ^{+0.3} _{+0.1}	$100_{-0.3}^{-0.1}$	40 ^{-0.080} -0.142	135	336	380	45	153	Stroke	354	398				
200	226	182	48	90	111	50	40 ^{+0.100}	25	50 ^{+0.3} _{+0.1}	$100_{-0.3}^{-0.1}$	$40^{-0.080}_{-0.142}$	135	336	380	45	153		354	398				
250	277	225	60	110	141	65	50 ^{+0.100}	30	63 ^{+0.3} _{+0.1}	$126^{-0.1}_{-0.3}$	$50^{-0.080}_{-0.142}$	160	411	466	55	176	0.17	427	482				
300	330	270	60	130	146	80	63 ^{+0.120}	37	80 ^{+0.3}	$160^{-0.1}_{-0.3}$	63 ^{-0.100}	175	451	519	55	190	stroke	466	534				

Note 1) Use only dehumidified and dust extracted clean compressed air as the air supply.

Note 2) Install a cylinder so that the cylinder rod might not be twisted.

Note 3) Do not apply force to the protective cover of the feedback spring.


Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.


Note 5) Do not use a lubricator.


Note 6) Cylinder dimensions are the same as those of the CS1 series. For details, refer to the WEB catalog or the Best Pneumatics No. 2.

Note 7) When using the cylinder outdoors, take measures to avoid wind and rain.

Center trunnion: CPS1T







Dimensions

(mm)

Dava sina	□В		_	s	тт	тх	TY	TZ	TZ ØTDe8 Without		Without rod boot With rod boot			t			
Bore size	⊔₽	□C	F	3	11	'^	11	12	L Ø I Des	Н	Z	ZZ	f	h	e	Z	ZZ
125	145	115	43	98	50	170	164	234	32 ^{-0.050} -0.089	110	159	227	40	133		182	250
140	161	128	43	98	55	190	184	262	36 ^{-0.050} -0.089	110	159	227	40	133		182	250
160	182	144	43	106	60	212	204	292	40 -0.050 -0.089	120	173	248	40	141	0.2 stroke	194	269
180	204	162	48	111	59	236	228	326	45 -0.050 -0.089	135	190.5	272	45	153	Stroke	208.5	290
200	226	182	48	111	59	265	257	355	45 ^{-0.050} _{-0.089}	135	190.5	272	45	153		208.5	290
250	277	225	60	141	69	335	325	447	56 ^{-0.060} _{-0.106}	160	230.5	331	55	176	0.17	246.5	347
300	330	270	60	146	79	400	390	534	67 ^{-0.060} -0.106	175	248	357	55	190	stroke	263.0	372


Note 1) If the air is not for pneumatic instrumentation, install a mist separator on the supply pressure side.

- Note 2) Install a cylinder so that the cylinder rod might not be twisted.
- Note 3) Do not apply force to the protective cover of the feedback spring.
- Note 4) The zero point is subject to the mounting position. Adjust zero point after installation on the site.
- Note 5) Do not use a lubricator.
- Note 6) Cylinder dimensions are the same as those of the CS1 series. For details, refer to the WEB catalog or the Best Pneumatics No. 2.
- Note 7) When using the cylinder outdoors, take measures to avoid wind and rain.




Series CPA2/CPS1 Dimensions of Accessories

Series CPA2



Single knuckle joint assembly




Double knuckle joint assembly


Bore	Dimensions of accessories							
size	Ø LA d9	LB	NX	NY	NZ			
50	12-0.050	74	16 ^{+0.3}	16 ^{-0.1} 0.3	38			
63	12-0.050	74	16 ^{+0.3}	16 ^{-0.1}	38			
80	18 ^{-0.050} _{-0.093}	87	28 ^{+0.3} _{+0.1}	28 ^{-0.1}	55			
100	20-0.065	102	30 ^{+0.3}	30_0.3	61			

^{*} A knuckle pin, split pins and flat washers are included with the double knuckle joint.

Series CPS1



Single knuckle joint



Double knuckle joint assembly

Bore	Dimensions of accessories							
size	Ø LA d9	LB	NX	NY	NZ			
125	25 ^{-0.065} -0.117	121	32+0.3	32-0.1	$64_{-0.3}^{-0.1}$			
140	28 ^{-0.065} -0.117	126	36+0.3	36-0.1	72 ^{-0.1}			
160	32 ^{-0.080} -0.142	134	40+0.3	40_0.3	80 ^{-0.1}			
180	40-0.080	151	50 ^{+0.3} _{+0.1}	50-0.1	100_0.3			
200	40-0.080	155	50 ^{+0.3} _{+0.1}	50-0.1	100-0.1			
250	50-0.080	198	63+0.3	63_0.3	126 ^{-0.1}			
300	63-0.100	217	80+0.3	80_0.3	160 ^{-0.1}			

^{*} A pin and split pins are included with the double knuckle joint.

Pneumatic Instrumentation Equipment

Detection Conversion Unit



Pressure Switches/Sensors

Pressure Switch/Micro Switch Type/IS100	Page 75
Pressure Switch/Reed Switch Type/IS10	Page 77
Pressure Switch/Micro Switch Type/IS3000	Page 77
General Purpose Pressure Switch/Snap Switch Type/ISG	Page 77
2-Color Display High-Precision Digital Pressure Switch/ZSE/ISE30A-	Page 77
2-Color Display Digital Pressure Switch/ISE70/75(H)	Page 77
2-Color Display Digital Pressure Switch/ZSE/ISE80 ··············	Page 77
Flow Switches/Sensors	
2-Color Display Digital Flow Switch/PFM	Page 78
2-Color Display Digital Flow Switch/PFMB	Page 78
Digital Flow Switch for Air/PF2A	Page 78
3-Color Display Digital Flow Switch for Water/PF3W	Page 78
3-Color Display Electromagnetic Type Digital Flow Switch/LFE	Page 78
Diaphragm Style Flow Switch/IFW5	Page 78
Paddle Style Flow Switch/IF3	Page 78



Pressure Switch/ Micro Switch Type Series IS100


• The pressure switch IS100 series can be utilized for automatic air pressure control in a wide variety of fields, such as industrial machinery or chemical plant.

Pressure adjustment range: 0.02 to 0.1 MPa

Electric wiring: Various wiring and entry methods can be selected.

Mechanical service life: 100,000 cycles


How to Order




Specifications


Model	IS100-02	IS101-02	IS112-02	IS113-02-□□	IS114-02-□□		
Proof pressure		0.2 MPa					
Pressure adjustment range		0.02 to 0.1 MPa					
Hysteresis		0.0015 MPa or less					
Repeatability	±5% F.S.						
Fluid	Air						
Ambient and fluid temperature	−5 to 60°C (No freezing)						
Port size	Rc1/4						
Rated voltage	125/250 VAC 5A, 30 VDC 5A						
Mechanical service life	100,000 cycles						

Symbol




Electrical circuit






Construction/Principle of Operation


Signal pressure enters the chamber above diaphragm ① and exerts downward force compressing spring ②. After sufficient deflection, contact with the plunger of the micro switch ③ is made operating the electrical circuit. As overtravel of diaphragm is prevented by an internal stop, the micro switch is not subject to extra load with increased pressure. On decrease of signal pressure the electrical circuit function is reversed. Contacts are available for N.C. or N.O. operation. Adjustment is carried out by removing cap ④ and rotating adjusting screw as required changing spring load.






Dimensions







IS114-02-□

Pressure Switches/Sensors

Best Pneumatics

Pressure Switch/Reed Switch Type IS10

•Small (Overall height 52 mm, Width 15 mm)



Series	Туре	Set pressure range	Contact
IS10	Positive pressure	0.1 to 0.4 MPa 0.1 to 0.6 MPa	Reed switch 1a

General Purpose Pressure Switch/Snap Switch Type ISG

- •For general fluids
- Equivalent to IP44 (ISG2∗□)
- •With indicator light (IS2761)
- With hysteresis adjusting function



Series	Туре	Set pressure range	Contact
ISG11□, 21□	Positive pressure	0.02 to 0.3 MPa	
ISG12□, 22□	Positive pressure	0.05 to 0.7 MPa	Snap switch 1a1b
ISG13□, 23□	Positive pressure	0.1 to 1.0 MPa	2ab
ISG19□, 29□	Vacuum pressure	-10 to -100 kPa	
IS2761	Positive pressure	0.1 to 1.0 MPa	1ab (Light 1b)

2-Color Display Digital Pressure Switch *ISE70/75(H)*

- •Metal body type (Aluminum die-casted)
- •IP67
- •With M12 connector



Series	Туре	Rated pressure range
ISE70	Positive pressure (for air)	0 to 1 MPa
ISE75	Positive pressure (for general fluids)	0 to 10 MPa
ISF75H	Positive pressure (for general fluids)	0 to 15 MPa

Pressure Switch/Micro Switch Type **IS3000**



•With neon light



Series	Туре	Set pressure range	Contact
IS3000	Positive pressure	0.1 to 0.7 MPa	Micro switch 1ab

2-Color Display High-Precision Digital Pressure Switch **ZSE/ISE30A**

- •With One-touch fitting (Straight, Elbow)
- Space-saving, Mountable side by side without clearance
- •With display calibration function
- Can copy to up to 10 switches simultaneously





Series	Туре	Rated pressure range		
ZSE30AF	Compound pressure	-100.0 to 100.0 kPa		
ZSE30A	Vacuum pressure	0.0 to -101.0 kPa		
ISE30A	Positive pressure	-0.100 to 1.000 MPa		

2-Color Display Digital Pressure Switch **ZSE/ISE80**

- Suitable for a wide variety of fluids with stainless diaphragm
- •IP65
- •Low leakage. VCR®, Swagelok® compatible fittings can be selected.
- •Rear ported, bottom ported



Series	Туре	Rated pressure range		
ZSE80F	Compound pressure	-100.0 to 100.0 kPa		
ZSE80	Vacuum pressure	0.0 to -101.0 kPa		
ISE80	Positive pressure	-0.100 to 1.000 MPa		
ISE80H	Positive pressure	-0.100 to 2.000 MPa		





Flow Switches/Sensors Best Pneumatics

2-Color Display Digital Flow Switch **PFM**



- Grease-free
- •3-step setting
- Integrated flow adjustment valve
- · Compact, lightweight, space-saving
- Panel mount, DIN rail, bracket, direct mounting



Series	Rated flow range (L/min)	
	0.2 to 10 (0.2 to 5)	
PFM	0.5 to 25 (0.5 to 12.5)	
(): For CO ₂	1 to 50 (1 to 25)	
()	2 to 100 (2 to 50)	

Flow Switches/Sensors

2-Color Display Digital Flow Switch **PFMB**

- Air, N₂
- •Grease-free
- Integrated flow adjustment valve (200 L type only)
- •Compact and space-saving



Series	Rated flow range (L/min)
	2 to 200
PFMB	5 to 500
	10 to 1000

Flow Switches/Sensors

Digital Flow Switch for Air **PF2A**

- Switch output, accumulated pulse output, analog output
- •IP65



Series	Rated flow range (L/min)
	1 to 10
	5 to 50
	10 to 100
PF2A	20 to 200
FIZA	50 to 500
	150 to 3000
	300 to 6000
	600 to 12000

Best Pneumatics 3-Color Display Digital Flow Switch for Water **PF3 V**

- •3-color/2-screen display
- Integrated flow adjustment valve and temperature sensor (4 L, 16 L, 40 L type only)
- •3-step setting
- •40% smaller than existing product (compared to PF2W)
- •IP65 compliant, non-grease type
- •Fluid temperature: 0 to 90°C
- Switch output, accumulated pulse output, analog output
- PVC piping type (10 to 100, 30 to 250 L/min only)

	· · ·
Series	Rated flow range (L/min)
	0.5 to 4
	2 to 16
PF3W	5 to 40
	10 to 100
	50 to 250 (30 to 250)

(): For PVC piping type

Flow Switches/Sensors

3-Color Display Electromagnetic Type Digital Flow Switch

LFE □


Compact, lightweight
 56 mm x 40 mm x 90 mm (H x W x D)
 Weight: 340 g (LFE1□3)

- Reverse flow can be detected.
- •Fluid temperature: 0 to 85°C
- Current consumption: 45 mA
- Applicable fluids: Water, water-soluble coolar

Applicable liulu	s. Water, water-soluble coolant	
Series	Rated flow range (L/min)	
	0.5 to 20	
LFE□	2.5 to 100	
	5 to 200	_

Flow Switches/Sensors Best Pneumatics

Diaphragm Style Flow Switch *IFW5*



With neon light



ĺ	Series	Set flow rate range (L/min)	Contact
		1 to 10	
	IFW5	10 to 20	Micro switch 1ab
		20 to 50	iab

Flow Switches/Sensors Best Pneumatics

Paddle Style Flow Switch IF3

- Used as a general relaying device when water stoppage or water volume reduction occurs during the use of a cooling water system, etc.
- Port size 3/4,1
- Equivalent to IP42 and IP44



Series	Set flow rate range (L/min)	Contact
	14 to 60	
IF3	20 to 1500	Micro switch 1ab
	36 to 2600	

Pneumatic Instrumentation Equipment

Solenoid Valves



Directional Control Valves

NAMUR Interface 3 Port Solenoid Valve/VFN200N	Page 80
NAMUR Interface 5 Port Solenoid Valve/VFN2000N	Page 83
NAMUR Interface 3/5 Port Solenoid Valve/	
IP67 Compliant, Hygienic Design Type/	
VFN2120N-X23/-X36	Page 90
Intrinsically Safe Explosion-proof System 5 Port Solenoid Valve/51-SY \cdots	Page 96
Explosion-proof Type 3/5 Port Solenoid Valve/ 50-VFE/50-VPE \cdots	Page 96
luid Control Equipment	
Direct Operated 2 Port Solenoid Valve/VX2······	Page 96
Pilot Operated 2 Port Solenoid Valve/VXD	Page 96



CE marking Nil

CE marked product

Q

Single solenoid

Double solenoid

Solenoid

NAMUR Interface 3 Port Solenoid Valve Series VFN200N

The interface surface complies with NAMUR.

• Can be directly installed on the industrial valve actuator that complies with NAMUR.

How to Order

VFN212 N - 5 -02|F

NAMUR Interface

Voltage •

1	100 VAC, 50/60 Hz	
2	200 VAC, 50/60 Hz	
3	110 to 120 VAC, 50/60 Hz	
4	220 VAC, 50/60 Hz	
5	24 VDC	
6	12 VDC	
7	240 VAC, 50/60 Hz	

For other rated voltages, please contact SMC.

Electrical entry

G	Grommet	
E	Grommet terminal	
Т	Conduit terminal	
D	DIN terminal	
DIN terminal (Without connector		
Y Note)	DIN terminal	
YO Note)	DIN terminal (Without connector)	

Note) Conforming to DIN 43650, Form B

Thread type Nil Rc (PT) G (PF) F Ν NPT

Manual override

Nil	Non-locking push type (Flush)	
Α	Non-locking push type (Extended)	
B Locking type (Tool required)		

Light/Surge voltage suppressor


Nil	None
Z	With light/surge voltage suppressor
S Note)	With surge voltage suppressor

Note) Available for grommet type only.

Specifications

Single solenoid

Symbol



	Fluid		Air, Inert gas			
	Valve type		Normally closed			
	Max. operating pressure		0.9 MPa (130 psi)			
	Min. operating pressure		0.15 MPa (22 psi)			
	Ambient and fluid temperat	ture	-10 to +60°C Note 1)			
Valve	Lubrication		Not required Note 2)			
specifications	Pilot valve manual override		Non-locking push type (Flush)			
	Enclosure		Dustproof			
	Port size		1/4			
	Cv factor (Effective area)		Refer to "Flow-rate Characteristics" table below.			
	Weight		Refer to "Weight" table below.			
	Other		Cylinder ports should be NAMUR hole pattern.			
	Coil rated voltage		12, 24 VDC, 100, 110 to 120, 200, 220, 240 VAC (50/60 Hz			
	Allowable voltage fluctuation		-15 to +10% of rated voltage			
	Coil insulation type		Class B or equivalent			
Electrical	Apparent power AC	Inrush	5.0 VA/60 Hz, 5.6 VA/50 Hz			
specifications	(Power consumption)	Holding	2.3 VA (1.5 W)/60 Hz, 3.4 VA (2.1 W) 9/50 Hz			
	Power consumption DC		1.8 W			
	Electrical entry		Grommet, Grommet terminal, Conduit terminal, DIN terminal			

Note 1) Use dry-air at low temperature. Note 2) Use turbine oil No.1 (ISO VG32), if lubricated.

Flow-rate Characteristics

		Flow-rate characteristics					
		1→4/2 (P→A/B)			4/2→5/3 (A/B→EA/EB)		
		С	b	Cv	С	b	Cv
0 !!!	Single solenoid	2.68	0.40	0.72	5.41	0.31	1.38
2-position	Double solenoid	2.68	0.40	0.72	5.41	0.31	1.38


Weight

Model	Weight
VFN212N-5D-02F	240
VFN212N-5D-02F-D	380


Series VFN200N


Dimensions

DIN terminal VFN212N-□_(Y)□□-02□-□













DIN terminal VFN212N-□(Y)□□-02□-D-□











Grommet




Conduit terminal VFN212N-□T□□-02□-□-□






Grommet terminal





NAMUR Interface 3 Port Solenoid Valve Series VFN200N

NAMUR Mounting Pattern




The solenoid valve can be attached with 2 mounting bolts.

The positioning of the coding stud hole is left up to the manufacturer and thus also determines the location of the coding stud.

NAMUR Interface 5 Port Solenoid Valve Series VFN2000N

The interface surface complies with NAMUR.



Specifications

	Fluid		Air, Inert gas		
	Max. operating pressure		0.9 MPa (130 psi)		
	Min. operating pressure		0.15 MPa (22 psi)		
	Ambient and fluid temperat	ture	-10 to +60°C Note 1)		
,, .	Lubrication		Not required Note 2)		
Valve specifications	Pilot valve manual override		Non-locking push type (Flush)		
Specifications	Enclosure		Dustproof		
	Port size		1/4		
	Cv factor (Effective area)		Refer to "Flow-rate Characteristics" table below.		
	Weight		Refer to "Weight" table below.		
	Other		Cylinder ports should be NAMUR hole pattern.		
	Coil rated voltage		12, 24 VDC, 100, 110 to 120, 200, 220, 240 VAC (50/60 Hz		
	Allowable voltage fluctuation		-15 to +10% of rated voltage		
	Coil insulation type		Class B or equivalent		
Electrical	Apparent power AC	Inrush	5.0 VA/60 Hz, 5.6 VA/50 Hz		
specifications	specifications (Power consumption) Hold		2.3 VA (1.5 W)/60 Hz, 3.4 VA (2.1 W) 9/50 Hz		

Note 1) Use dry-air at low temperature.

Note 2) Use turbine oil No.1 (ISO VG32), if lubricated.

Electrical entry

Power consumption DC

Flow-rate Characteristics

		Flow-rate characteristics					
		1→4/2 (P→A/B)			4/2→5/3 (A/B→EA/EB)		
		С	b	Cv	С	b	Cv
2-position	Single solenoid	3.48	0.25	0.85	4.57	0.17	1.06
	Double solenoid	3.48	0.25	0.85	4.57	0.17	1.06

Weight

(g)

Model	Weight
VFN2120N-5D-02F	260
VFN2220N-5D-02F	400

1.8 W Grommet, Grommet terminal,

Conduit terminal, DIN terminal


Symbol


Single solenoid

Double solenoid


<u>ද</u>් සු


Dimensions















DIN terminal

VFN2220N-□(Y)□□-02□-□










Conduit terminal

Grommet


VFN2120N-□G□□-02□-□




VFN2120N-□T□□-02□-□ 148











Series VFN2000N

NAMUR Mounting Pattern



The solenoid valve can be attached with 2 mounting bolts.

The positioning of the coding stud hole is left up to the manufacturer and thus also determines the location of the coding stud.





NAMUR Interface Solenoid Valves Specific Product Precautions 1

Be sure to read this before handling.

Design

⚠ Warning

1. Actuator drive

When an actuator, such as a cylinder, is to be driven using a valve, take appropriate measures to prevent potential danger caused by actuator operation.

2. Holding pressure (including vacuum)

Since the valves are subject to air leakage, they cannot be used for applications such as holding pressure (including vacuum) in a pressure vessel.

3. Not suitable for use as an emergency shutoff valve, etc.

The valves are not designed for safety applications such as an emergency shutoff valve. If the valves are used for the mentioned applications, additional safety measures should be adopted.

4. Ensure sufficient space for maintenance activities.

When installing the products, allow access for maintenance.

5. Release of residual pressure

For maintenance purposes install a system for releasing residual pressure.

Selection

⚠ Warning

1. Confirm the specifications.

Products are designed only for use in compressed air systems (including vacuum). Do not operate at pressures or temperatures, etc., beyond the range of specifications, as this can cause damage or malfunction. (Refer to the specifications.) Please contact SMC when using a fluid other than compressed air (including vacuum).

2. Extended periods of continuous energization

Please contact SMC when a valve is continuously energized for an extended period of time or when the energized period is longer than the de-energized period.

∧ Caution

1. Momentary energization (Double solenoid valve)


If a double solenoid valve is operated with momentary energization, it should be energized for at least 0.1 second. However, depending on the condition of the secondary load, it should be energized until the cylinder reaches the stroke end position, since there is a possibility of malfunction.

Selection

⚠ Caution

2. Leakage voltage

Take note that the leakage voltage will increase when a C-R circuit (surge voltage suppressor) is used for protecting a switching device because of the passing leakage voltage through the C-R circuit.



The suppressor residual leakage voltage should be as follows. DC coil: 3% or less of rated voltage

AC coil: 20% or less of rated voltage

3. Solenoid valve drive with SSR

If the minimum load current of the SSR is larger than that of the solenoid valve, this may cause a malfunction.

When selecting the SSR, refer to the element catalog specifications.

4. Surge voltage suppressor

If a surge protection circuit contains nonstandard diodes, such as Zener diodes or ZNR, a residual voltage that is in proportion to the protective circuit and the rated voltage will remain. Therefore, take into consideration the surge voltage protection of the controller.

In the case of diodes, the residual voltage is approximately 1 $\ensuremath{\text{V}}$.

5. Operation in a low temperature condition

It is possible to operate a valve in extreme temperature, as low as -10° C. Take appropriate measures to avoid freezing of drainage, moisture etc. in low temperature.

6. Mounting orientation

Mounting orientation of a single solenoid valve is universal. When installing a double solenoid valve, mount the valve so that spool valve is horizontal.

Mounting

Marning

1. If air leakage increases or equipment does not operate properly, stop operation.

Check mounting conditions when air and power supplies are connected. Initial function and leakage tests should be performed after installation.

2. Operation manual

Install the products and operate them only after reading the operation manual carefully and understanding its contents. Also, keep the manual where it can be referred to as necessary.

3. Painting and coating

Warnings or specifications printed or affixed to the product should not be erased, removed or covered up. Also, applying paint to resinous parts may have an adverse effect due to the solvent in the paint.





NAMUR Interface Solenoid Valves Specific Product Precautions 2

Be sure to read this before handling.

Piping


⚠ Caution

1. Preparation before piping

Before piping is connected, it should be thoroughly blown out with air (flushing) or washed to remove chips, cutting oil and other debris from inside the pipe.

2. Wrapping of sealant tape

When screwing piping or fittings into ports, ensure that chips from the pipe threads or sealing material do not enter the piping. Also, if sealant tape is used, leave 1.5 to 2 thread ridges exposed at the end of the threads.



3. Connection of fittings

When attaching fittings to valves, tighten with the tightening torque shown below.

Connection thread size	Proper tightening torque N·m(kgf·cm)
1/4	12 to 14 (120 to 140)

4. Piping to products

When piping to a product, refer to the operation manual to avoid mistakes regarding the supply port, etc.

Wiring

⚠ Caution

1. Applied voltage

When electric power is connected to a solenoid valve, be careful to apply the proper voltage. Improper voltage may cause malfunction or coil damage.

2. Check the connections.


Check if the connections are correct after completing all wiring.

Light/Surge Voltage Suppressor

⚠ Caution

AC and 100 VDC

Single Terminal No.1(+) With indicator light




24 VDC or less

Single

Terminal No.1(+) With indicator light

+(-) SOL.

Terminal No.2(-) Note) There is no polarity (+, -).




•Type G: Use lead wire from solenoid to connect with power side. Grommet with DC voltage surge voltage suppressor has polarity. Connect red lead wire to + (positive) side and black to – (negative) side.

Surge voltage suppressor				
DC	AC			
Red+	Varistor			

Wiring

⚠ Caution

In the case of DIN terminal and terminal block (with indicator light/surge voltage suppressor), the interior wiring is shown below.



Applicable terminal: 1.25-3, 1.25-3S, 1.25Y-3N, 1.25Y-3S, but in the case of with DIN terminal block, is not a terminal structure.

Note) There is no polarity (+, -).





NAMUR Interface Solenoid Valves Specific Product Precautions 3

Be sure to read this before handling.

Changing Direction of DIN Terminal/Cable Entry

⚠ Caution

To change direction of DIN terminal retaining screw, pull off outer cover, rotate connector board through 180°. Replace cover and tighten screw.



Lubrication

⚠ Caution

1. Lubrication

- 1) The valve has been lubricated for life at the factory, and does not require any further lubrication.
- 2) If a lubricant is used in the system, use class 1 turbine oil (no additive), ISO VG32. Once a lubricant is used in the system, lubrication must be continued because the original lubricant applied during manufacturing will be washed away. Refer to each manufacturer's brand name of class 1 turbine oil (no additive), ISO VG32 as shown below.

Class 1 Turbine Oil (No additive), ISO VG32

olass i raibile sii (its additivs), iss vasz					
Classification of viscosity Viscosity according to ISO Grade	32				
Idemitsu Kosan Co., Ltd.	Turbine oil P-32				
Nippon Oil Corporation	Turbine oil 32				
COSMO OIL CO., LTD.	Cosmo turbine 32				
Japan Energy Corporation	Kyodo turbine 32				
Kygnus Sekiyu K.K.	Turbine oil 32				
Kyushu Oil Co., Ltd.	Stork turbine 32				
Mitsubishi Oil Co., Ltd.	Mitsubishi turbine 32				
SHOWA SHELL SEKIYU K.K.	Turbine 32				
Tonen General Sekiyu K.K.	General R turbine 32				
FUJI KOSAN CO., LTD.	Fukkol turbine 32				

Please contact SMC for details about class 2 turbine oil (with additives), ISO VG32.

Air Supply

Marning

1. Use clean air.

Do not use compressed air that contains chemicals, synthetic oils including organic solvents, salt or corrosive gases, etc., as it can cause damage or malfunction.

∧ Caution

1. Install an air filter.

Install an air filter upstream near the valve. Select an air filter with a filtration size of 5 μm or smaller.

Air Supply

⚠ Caution

2. Take measures to ensure air quality, such as by installing an aftercooler, air dryer, or water separator.

Compressed air that contains a large amount of drainage can cause malfunction of pneumatic equipment such as valves. Therefore, take appropriate measures to ensure air quality, such as by providing an aftercooler, air dryer, or water separator.

If excessive carbon powder is seen, install a mist separator on the upstream side of the valve.

If excessive carbon dust is generated by the compressor, it may adhere to the inside of a valve and cause it to malfunction.

For compressed air quality, refer to SMC Best Pneumatics catalog.

Operating Environment

⚠ Warning

- 1. Do not use in an atmosphere having corrosive gases, chemicals, sea water, water, water steam, or where there is direct contact with any of these.
- 2. Do not use in explosive atmospheres.
- 3. Do not use in a place subject to heavy vibration and/or impact.

Confirm the specifications in the main section of the catalog.

- 4. The valve should not be exposed to prolonged sunlight. Use a protective cover.
- 5. Remove any sources of excessive heat.
- 6. In locations where there is contact with spatter from water, oil, solder, etc., take suitable protective measures.
- 7. When the solenoid valve is mounted in a control panel or its energized for a long time, make sure ambient temperature is within the specification of the valve.





NAMUR Interface Solenoid Valves Specific Product Precautions 4

Be sure to read this before handling.

Maintenance

⚠ Warning

1. Perform maintenance inspection according to the procedures indicated in the operation manual.

If handled improperly, malfunction and damage of machinery or equipment may occur.

2. Removal of equipment, and supply/exhaust of compressed air

When components are removed, first confirm that measures are in place to prevent workpieces from dropping, run-away equipment, etc. Then, cut off the supply pressure and electric power, and exhaust all compressed air from the system using the residual pressure release function. For 3-position closed center type, exhaust the residual pressure between the valve and the cylinder.

When the equipment is operated after remounting or replacement, first confirm that measures are in place to prevent lurching of actuators, etc. Then, confirm that the equipment is operating normally.

3. Low frequency operation

Valves should be operated at least once every 30 days to prevent malfunction. (Use caution regarding the air supply.)

4. Manual override

When the manual override is operated, connected equipment will be actuated. Operate after safety is confirmed.

⚠ Caution

1. Drain flushing

Remove drainage from the air filters regularly.


2. Lubrication

Once lubrication has been started, it must be continued. Use class 1 turbine oil (with no additive), VG32. If other lubricant oil is used, it may cause malfunction. Please contact SMC for suggested class 2 turbine oil (with additive), VG32.



NAMUR Interface 3/5 Port Solenoid Valve IP67 Compliant, Hygienic Design Type VFN2120N-X23/-X36

- Hygienic design is adopted Resin body with less concaves. Direct cleaning of valve is possible (IP67)
- 3 port/5 port available Function plate realized 3/5 port selectable
- Low power consumption Power consumption: 0.5 W
- Port threads: NPT1/4, G1/4 available



VFN2120N-X23/-X36

Standard Specifications


Fluid	Air		
Operating pressure range	0.15 to 0.9 MPa		
Ambient and fluid temperature	–10 to +60°C		
Lubrication	Not required		
Manual override	Push type/Locking type (tool required)/ Locking type (manual type)		
Enclosure	Equivalent to IP67		
Thread port size	1/4"		
Flow-rate characteristics (Cv/Effective area)	0.8/11 mm ²		
Rated voltage	24 VDC		
Allowable voltage fluctuation	-15 to +10% of rated voltage		
Type of coil insulation	Class B		
Power consumption	0.5 W		

Replacement Parts

1)Mounting screw				
Model	Type	Co	ntents	
AXT842-30-19A-2	UNF10-32	With wa	asher/A set	
AXT842-30-19A-3	M5 x 0.8	of 10 screws		
②Check valve		Mo		
Model	Conter	nts		Ĭ
AXT842-30-17A	A set of 1	0 pcs.	1 7	

3Function	plate	assembly [®]
OI WIIOUOII	piato	accention

<u> </u>			
Model Valve specificati			
AXT842-30-10-A	3 port (Coil side: A port)		
AXT842-30-10-B	5 port (Coil side: B port)		
AXT842-30-10-C	3 port (Coil side: B port)		
AXT842-30-10-D	5 port (Coil side: A port)		




Check valve

Options


Throttle valve spacer

Part no.	Mounting screw type	Body material	Accessories	
AXT842-30-22A-1	UNF10-32	Stainless steel		
AXT842-30-22A-2	M5 x 0.8	Stainless steel	O-ring for interface (2 pcs.)	
AXT842-30-24A-1	UNF10-32	Aluminum	Mounting screw for spacer (2 pcs.)	
AXT842-30-24A-2	M5 x 0.8	(Black anodized)	(Black anodized)	

Dimensions











Adjusting screw for throttle (A side/B side)

^{*} Valve specifications can be freely changed by changing the function plate.

Dimensions




Electrical entry: Vertical VFN2120N-X23B




VFN2120N-X23/-X36


Dimensions




Electrical entry: Vertical VFN2120N-X23D



Dimensions




Electrical entry: Horizontal VFN2120N-X36B




SMC

VFN2120N-X23/-X36

Dimensions



Electrical entry: Horizontal VFN2120N-X36D



Directional Control Valves

For details, refer to the SMC website.

http://www.smcworld.com

Intrinsically Safe Explosion-proof System 5 Port Solenoid Valve 51-SY

Operation unit

- ulletExia ${\mathbb I}$ BT4 (TIIS approved product)
- Three types of electrical entry
 L-type plug connector, L-type plug connector with cover, Terminal type
- •Three types of barriers can be selected.



	Flow-rate characteristics			Power
Series	4/2→5/3 (A/B→EA/EB)			consumption
	C [dm³/(s·bar)]	b	Cv	(W)
51-SY5000	2.8	0.29	0.66	
51-SY7000	4.1	0.29	1.0	0.52
51-SY9000	9.6	0.43	2.6	

Explosion-proof Type 3/5 Port Solenoid Valve 50-VFE/50-VPE

Operation unit


- $\bullet \text{d2G4}$ and Exd ${\rm I\hspace{-.1em}I}$ BT4 (TIIS approved product)
- •Waterproof: Passed the IPX6 test.
- Exhausting equipment for pilot valve not required.
 (Common exhaust type for main and pilot valve [50-VFE3000])
- Possible to be into manifold (50-VFE)
- As a selector valve, divider valve, or able to use for vacuum applications. (50-VPE)

use for vacuum applications. (50-VPE)			
Series		Effective area mm² (Cv)	Power consumption (W)
50-VFE3000		18 (1.0)	
50-VFE5000	5 port	45 (2.5)	0.5
50-VPE500	0	41.4 (2.3)	3.5
50-VPE700	3 port	72 (4)	

Best Pneumatics

Pilot Operated 2 Port Solenoid Valve

Fluid control equipment



•Height: 7% smaller*



Series	Valve type	Port size	Orifice diameter (mmø)
VXD2	N.C./N.O.	1/4 to 1 32 A to 50 A ø10, ø3/8", ø12	10 to 50

^{*} Comparison with SMC conventional model

Fluid Control Equipment

Direct Operated 2 Port Solenoid Valve VX2

Fluid control

- For air, medium vacuum, water, oil, steam
- Flow rate: 20% more flow*
- •Height: 10% smaller*
- Lightweight: 30% lighter*
- Body material: Aluminum, resin (air), C37, stainless steel (water, oil, medium vacuum)
- Available with One-touch fittings (resin body)

Series	Valve type	Port size	Orifice diameter (mmø)
VX21/22/23	N.C./N.O.	1/8 to 1/2 ø6 to ø12	2 to 10

^{*} Comparison with SMC conventional model

Pneumatic Instrumentation Equipment

Air Preparation Equipment



Aftercoolers	
Air Cooled Aftercooler/HAA	
Water Cooled Aftercooler/HAW	Page 98
Air Tanks	
Air Tank/VBAT	
Air Tank/ AT	Page 98
Air Dryers	
Refrigerated Air Dryer/IDF/IDU□E, D	Page 98
Refrigerated Air Dryer/Large Size Series/IDF□F	Page 98
Refrigerated Air Dryer: For Use in Europe, Asia, and Oceania/IDFA	∃E Page 98
Refrigerated Air Dryer/Large Size Series: For Use in Europe, Asia, a	
IDFA F	Page 98
Refrigerated Air Dryer: For Use in North, Central and Sout	
IDFB□E ·····	Page 99
Heatless Air Dryer/ID	Page 99
Membrane Air Dryer/IDG	Page 99
Filters	
Water Separator/AMG	Page 99
Main Line Filter/AFF	Page 99
Mist Separator/AM	Page 99
Micro Mist Separator/AMD	Page 99
Micro Mist Separator with Pre-filter/AMH	Page 100
Super Mist Separator/AME	Page 100
Odor Removal Filter/AMF	



Positioners

Air Cooled Aftercooler HAA

Aftercoolers

- Can cool high temperature compressed air from compressors down to 40° C or less and efficiently remove moisture from the air
- · Cooling equipment is not required for this air cooled type.
- Maintenance is easy and the running cost is reasonable since this is free from concerns such as water supply cut-off or freezing.



Series	Applicable compressor	Air flow capacity L/min (ANR)
HAA	7.5 to 37 kW	1000 to 5700

Water Cooled Aftercooler HAW

- Can cool high temperature compressed air from compressors down to 40° C or less and efficiently remove moisture from the air
- Stable operation is possible even in an environment with a high temperature, high moisture and heavy foreign particles for this water cooled type.



Series	Applicable compressor	Air flow capacity L/min (ANR)	
HAW	2.2 to 110 kW	300 to 18000	

Best Pneumatics

Air Tanks

Air Tank VBAT

- Compact air tank
- Compact connections are possible with booster regulators.
- Can be used as an independent tank.
- Also partially compatible with overseas standards
- Material: Carbon steel. Stainless steel



Series	Port size	Tank capacity (L)
VBAT	3/8, 1/2, 3/4	5, 10, 20, 38

Air Tank AT

- Accumulates the compressed air from compressors, also prevents it from being pulsated, and cools it.
- Use outside Japan is not allowed. The AT series air tank is in compliance with the regulations in Japan (Class 2 Pressure Vessel), but is not in compliance with related regulations outside Japan. (This is also applicable when the series is used as a unit.) Please consult with SMC for use of air tanks outside Japan.
- Material: Carbon steel



Series	Port size	Tank capacity (L)
AT	1/2 to 4 ^B flange	100 to 3000

Best Pneumatics

Air Dryers

Refrigerated Air Dryer *IDF/IDU* □ *E, D*

- Air flow capacity: Increased by up to 40%* (SMC comparison)
- Power consumption: Reduced by up to 40%* (SMC comparison)
- Refrigerant: R134a (HFC) [IDF1E to 15E1/IDU3E to 15E1] R407C (HFC) [IDF22E to 370D/IDU22E to 75E]
- Improved corrosion resistance with the stainless steel heat exchanger (IDF4E to 75E/IDU3E to 75E)



* Series IDF□E/IDU□E

	Applicable	Air flow capacit	y m³/min (ANR)
Series	compressor	50 Hz	60 Hz
IDF1E to 75E	0.75 to 75 kW	0.10 to 11.0	0.12 to 12.4
IDF190D to 370D	190 to 370 kW	32.0 to 54.0	38.0 to 65.0
IDU3E to 75E	2.2 to 75 kW	0.32 to 11.0	0.37 to 12.5

Refrigerated Air Dryer: For Use in Europe, Asia, and Oceania $IDFA \square E$

- •EC Directive compliant product (with CE mark)
- Power supply voltage: Single-phase 230 VAC
- Refrigerant: R134a (HFC), R407C (HFC). Coefficient of destruction for ozone is zero
- Improved corrosion resistance with the use of stainless steel, plate type heat exchanger (IDFA4E to 75E)



	Air flow capacity m³/h (ANR)			_
Series	Outlet air pressure dew point		Compliant standard	
	3°C	7°C	10°C	
IDFA3E to 75E	12 to 660	15 to 720	17 to 822	CE

Refrigerated Air Dryer/Large Size Series

- Tolerant of high temperature environment (Ambient temperature 45°C, Inlet air temperature 60°C)
- Exhaust heat amount is reduced by 25%.
- · Air-cooled and water-cooled types are available
- Stainless steel heat exchanger
- Refrigerant: R407C (HFC)




Air-cooled type Water-cooled type

Series	Applicable Air flow capacity m³/min (Al		y m³/min (ANR)
	compressor	50 Hz	60 Hz
IDF100F	100 kW	16	18.8
IDF125F	125 kW	20.1	23.7
IDF150F	150 kW	25	30

Refrigerated Air Dryer/Large Size Series: For Use in Europe, Asia, and Oceania

- $IDFA \square F$
- Tolerant of high temperature environment (Ambient temperature 45°C, Inlet air temperature 60°C)
- Exhaust heat amount is reduced by 25%.
- Power supply voltage: Three-phase 380 VAC (for Asia and Oceania), 400 VAC (for Europe)
- Stainless steel heat exchanger
- Refrigerant: R407C (HFC)





Air Dryers

Refrigerated Air Dryer: For Use in North, Central and South America IDFB E

- •UL certified product
- Power supply voltage: Single-phase 115 VAC, 230 VAC (60 Hz), Three-phase 460 VAC (60 Hz)
- Refrigerant : R134a (HFC), R407C (HFC) Coefficient of destruction for ozone is zero.
- Improved corrosion resistance with the use of stainless steel, plate type heat exchanger (IDFB4E to 75E)



	Air flow capacity m³/h (ANR)			
Series	Outlet air pressure dew point			Compliant
	37°F (2.8°C)	45°F (7.2°C)	50°F (10°C)	
IDFB3E to 75E	10 (17) to 300 (510)	11 (19) to 353 (600)	12 (20) to 406 (690)	UL, CSA

Membrane Air Dryer *IDG*

- •Non-fluorocarbon
- Power supply not required
- · Compatible with low dew point
- •No vibration or heat discharge
- •With a dew point indicator



Series Outlet air flow rate L/min		Standard dew point (°C)
IDG1 to 100 10 to 1000		-20
IDG3H to 100H	25 to 1000	-15
IDG30LA to 100LA	75 to 300	-40
IDG60SA to 100SA	50 to 150	-60

Best Pneumatics

Heatless Air Dryer ID

- Supply dry air with a low dew point below -30°C.
- Compact and lightweight without heater and electric control board.
- Possible to check the outlet dew point with the indicator. (Self-regenerative style allows for easy maintenance.)



Series	Outlet air flow rate L/min (ANR)
ID	80 to 780

Filters

Water Separator AMG

- Eliminates water droplets in the compressed air.
- •Water droplet removal rate: 99%



Series	Air flow capacity L/min (ANR)	Port size
AMG	AMG 300 to 12000	

Main Line Filter *AFF*

 Can remove impurities such as oil, water and foreign matter in compressed air and can improve the function of a dryer in the downstream, extend the life of precision filter, and prevent trouble with the equipment.



Series	Filtration rating (μm)	Rated flow L/min (ANR)	Port size
AFF	3 (Filtration efficiency: 99%)	300 to 45000	1/8 to 2, JIS 10KFF flange 2 to 4 ^B

Best Pneumatics

Mist Separator AM

• Can remove oil mist in compressed air and separate and remove particles such as rust or carbon of 0.3 μm or more.



Series	Filtration rating (μm)	Rated flow L/min (ANR)	Port size
АМ	0.3 (Filtration efficiency: 99.9%)	300 to 12000	1/8 to 2

Micro Mist Separator AMD

- Can separate and remove aerosol state oil mist in compressed air and remove particles such as carbon or dust of 0.01 μm or more.
- Use this product as a pre-filter for compressed air for precision instruments or clean room requiring higher clean air.



Series	Filtration rating (μm)	Rated flow L/min (ANR)	Port size
AMD	O.O1 (Filtration efficiency: 99.9%)	200 to 40000	1/8 to 2, JIS 10KFF flange 2 to 6 ^B





Filters Best Pneumatics

Micro Mist Separator with Pre-filter AMH

- The AM series + AMD series have been integrated to achieve a reduction in installation space and in piping labor.
- Can separate and remove aerosol state oil mist in compressed air and remove particles such as carbon or dust of 0.01 μm or more.
- Use this product as a pre-filter for compressed air for precision instruments or clean room requiring higher clean air.



Series	Filtration rating (μm)	Rated flow L/min (ANR)	Port size
АМН	O.O1 (Filtration efficiency: 99.9%)	200 to 12000	1/8 to 2

Super Mist Separator AME

- Can separate and adsorb aerosol state fine oil particles in compressed air and change the oil lubricating compressed air to oilless air or equivalent.
- Use this product for filtration of compressed air requiring higher clean air for painting lines, compressed air for clean rooms and/or equipment where oils must be avoided.



Seri	ies	Filtration rating (μm)	Rated flow L/min (ANR)	Port size
AN	ΙE	O.O1 (Filtration efficiency: 99.9%)	200 to 12000	1/8 to 2

Odor Removal Filter AMF

- Efficiently can remove odor in compressed air with an activated carbon element. Use this product in the area such as a clean room where odors must be avoided.
- Activated carbon element with large filtration



Series	Filtration rating (μm)	Rated flow L/min (ANR)	Port size
AMF	O.O1 (Filtration efficiency: 99.9%)	200 to 40000	1/8 to 2, JIS 10KFF flange 2 to 6 ^B

Pneumatic Instrumentation Equipment

Industrial Filters



Industrial Filters

Industrial Filter/ FGD	Page 102
Industrial Filter/ FGE	Page 102
Industrial Filter/ FGG	Page 102
Bag Filter/ FGF	Page 102
High Precision Filter for Liquids/FGH	Page 102
Quick Change Filter/FQ1	Page 102
Elements	
Sintered Metal Filter Elements/EB/ES	Page 103
Fiber Elements/ EH/EHM/EHK	Page 103
•	Page 103
Micromesh Elements/EM ·····	Page 103



Best Pneumatics

Industrial Filters

Industrial Filter FGD

- •Low flow rate filtration (Max. 60 L/min)
- Possible to select the antistatic specification (FGDE, FGDF).
- •Can be used with a wide range of fluids as iron or stainless steel 316 bowl is used.



Series	Port size	Max. operating pressure	Operating temperature (°C)
FGD	Rc3/8, 1/2, 3/4	0.7, 1 MPa	Max. 80

Industrial Filter FGG

- High flow rate filtration (Max. 350 L/min)
- Element replacement is easy with the V-band type. (With cover anti-scattering mechanism)



Series	Port size	Max. operating pressure	Operating temperature (°C)
FGG	Rc2	0.7 MPa	Max. 80

High Precision Filter for Liquids FGH

- Filtration efficiency: 99% or more
- \bullet Filtration rating: 0.2, 0.4, 2, 4, 6, 13 μm are selectable.



Ì	Series	Port size	Max. operating pressure	Operating temperature (°C)
	FGH	Rc3/8 to 1	1 MPa	Max. 80

Industrial Filter FGE

- •Medium flow rate filtration (Max. 230 L/min)
- •Element replacement is easy with the V-band type. (With cover anti-scattering mechanism)
- The bolt tightening type can be used with a wide range of fluids as fluoropolymer gasket and stainless steel 304 bowl are used.



Series	Port size	Max. operating pressure	Operating temperature (°C)
FGE	R1, 2	0.7 MPa	Max. 80

Bag Filter *FGF*

- Highly effective for filtration of high turbidity and high viscosity fluids
- High flow rate filtration (Max. 2000 L/min)
- •The bag type element catches solid foreign matter, ensuring easy treatment.
- Suitable for filtering cleaning fluids



Series	Port size	Max. operating pressure	Operating temperature (°C)
FGF	Rc2, 4 ^B flange, 6 ^B flange	0.5 MPa	Max. 80

Quick Change Filter FQ1

- •Low flow rate filtration (Max. 30 L/min)
- No tools required.
- Easy element replacement



١.				
	Series	Port size	Max. operating pressure	Operating temperature (°C)
	FQ1	Rc1/2, 3/4, 1	1 MPa	Max. 80

Elements Best Pneumatics

Sintered Metal Filter Elements EB/ES

- Outstanding mechanical strength, heat resistance and chemical resistance.
- Formed by sintering finely powdered metal, so a high filtration accuracy can be obtained.
- Even if clogging progresses, the element can be reused by cleaning.
- Main applications Ideal as a check filter for keeping fluid clean.
 All types of gases, fluids, general solvents and high-temperature fluids



Series	Material	Nominal filtration accuracy (μm)
EB	Bronze	1, 2, 5, 10, 20
ES	Stainless steel 316	40, 70, 100, 120


Paper Elements *EP*

- Cartridges are pleated for a large filtration area, and elements are economical due to their long service life.
- Main applications
 Ideal for filtration of hydraulic oil, lubricating oil, fuel oil, oils for the liquid gas industry, dry inert gases, and dry air.



Series	Material	Nominal filtration accuracy (µm)
EP	Filter paper (Cotton, Phenol resin impregnated paper)	5, 10, 20

Fiber Elements EH/EHM/EHK



- Elements are economical because particle capturing capacity is excellent, and element life is long.
- Elements are disposable so maintenance and replacement are easy.
- Main applications

	• Main applications	
	Cotton	Cleaning water, General neutral fluids,
	Collon	General solvents, Dry air
	Polypropylene	Plating fluids, General acids, Alkali fluids,
		Industrial water, Cooling water
	Glass fiber	Acid fluids, High-temperature fluids



Series	Element material	Core material	Nominal filtration accuracy (µm)
EH	Cotton	Stainless steel 304	0.5, 1.5, 10, 20
EHM	Polypropylene	Polypropylene	50, 75, 100
EHK	Glass fiber	Stainless steel 316	1, 5, 10, 20

Micromesh Elements EM

- Stainless steel metal mesh has high filtration accuracy.
- Outstanding heat and chemical resistance. Applicable to a wide range of applications.
- Pleated type has 3 times the filtration area of a cylinder.
- Filters are economical because they can be cleaned and repeatedly used.
- Main applications

Please use 40 microns or less as a high precision filter, and 74 microns or higher as a high-grade strainer.

All types of gases and fluids, high-temperature fluids



Series	Material	Jointing material	Nominal filtration accuracy (µm)
EM100	Stainless steel 304	Epoxy resin	5, 10, 20
EM500	Stainless steel 316	_	40, 74, 105





Pneumatic Instrumentation Equipment

Piping Materials



Tubing

Double-layered Tubing for Instrumentation Device (Single-tubed/Dou	ible-tubed)/
IN-241	Page 105
T0604 to T1075-X120/121/166	Page 105
Reinforced Corrugated Cardboard Specification: Longer Lea	ngth Reel/
T0604-X64/TH0604-X64	Page 107
Polyurethane Coil Tubing/TCU	Page 110
Longer Length Reel/-X3	Page 110
Fittings/S Couplers	
Stainless Steel 316 One-touch Fittings/KQG2	Page 110
Stainless Steel 316 Insert Fittings/KFG2	Page 110
S Couplers: Stainless Steel Type/KKA	Page 110

Double-layered Tubing for Instrumentation Device (Single-tubed/Double-tubed)

Series IN-241 Series T0604 to T1075-X120/121/166

- Double-layered tubing with an external layer of vinyl chloride or polyolefin to protect the inner tubing
- Inner tubing color: "Black" or "Black + White"

Standard Specifications



Fluid	Air			
May anausting mysessus	Inner tubing O.D. ø6 : 3.0 MPa			
Max. operating pressure (at 20°C)	ø8 : 2.0 MPa			
	ø10: 2.0 MPa			
Ambient and fluid temperature	−40 to +100°C			
Inner tubing material	Nylon			
Outer layer color	Black			
Weight (Reference)	37 kg (T1075-2-300-X166)			


Model	Diameter	Number of cores		Inner tubing color		Material		Outer layer thickness (mm)		Length per roll				
Model	(mm)	1	2	Black	Black +	,	Polyolefin	0.5	1	100) m	200 m	300) m
			_	Biaon	White	chloride	roryoromi	0.0	·	Reel	Roll	Reel	Reel	Roll
IN-241-2522-100		•		•			•	•		•				
IN-241-2522-300	0.5	•		•			•	•					•	
T0604-1-100-X120-A	O.D. ø6	•		•		•			•	•				
T0604-1-300-X120-A		•		•		•			•				•	
T0604-2-100-X120-A	I.D. ø4		•		•	•			•	•				
T0604-2-100-X121-A			•		•	•			•	•				
IN-241-1047			•		•	•			•			•		
IN-241-2523-100		•		•			•	•		•				
IN-241-2523-300	O.D.	•		•			•	•					•	
T0806-1-100-X120-A	ø8	•		•		•			•	•				
T0806-1-300-X120	I.D.	•		•		•			•					•
IN-241-2502-100	ø6		•	•			•	•			•			
IN-241-2593-100			•		•		•	•			•			
T1075-1-100-X120-A	0.0	•		•		•			•	•				
T1075-1-300-X120	O.D. ø10	•		•		•			•					•
IN-241-2503-100			•	•			•	•			•			
IN-241-2594-100	I.D. ø7.5		•		•		•	•			•			
T1075-2-300-X166	97.3		•		•		•	•					•	

^{*} If you need a different number of cores, different colors or lengths over 300 m, please contact our sales representatives.



Dimensions

Number of cores: 1 core



Tube size O.D. (ØD) x I.D. (Ød) ø6 x ø4 ø8 x ø6


ø10 x ø7.5

Outer layer Thickness (t)

* The outer layer thickness for X120 is 1 mm only.

Number of cores: 2 cores

•IN-241-1047 •T0604-2-100-X120-A




•T0604-2-100-X121-A

Part no. indication at every 150 mm (excluding the digits for roll length and "-A"), Character height: 1.2 mm, Color: Gold T0604-2-X121

* The part no. is indicated on the product only for $T\Box\Box\Box\Box$ -X120 and X121.

Except above mentioned tubing



* Inner tubing color: If both of the inner tubing are black, one of them will have a line.

Tube size

O.D. (ØD) x I.D. (Ød)
ø8 x ø6
ø10 x ø7.5

Outer layer

Cutor layor	_
Thickness (t)	
0.5	7
1	٦

Width

O.D. (ØD) x I.D. (Ød)	Thickness (t)	Width (A)
~9 v ~6	0.5	17
ø8 x ø6	1	18
ø10 x ø7.5	0.5	21
	1	22

Reinforced Corrugated Cardboard Specification/Longer Length Reel

Nylon Tubing

T0604-X64



- Length per roll: 500/250 m
- For general pneumatic tubing
- Nylon Tubing




How to measure the minimum bending radius



At a temperature of 20°C, bend the tubing into a U shape. Fix one end and gradually move the other end closer. Measure 2R at the point where the outside diameter's rate of change is 10%.

Max. Operating Pressure



Series


Model	T0604
Tubing O.D. (mm)	6
Tubing I.D. (mm)	4
Black (B)	
Bidok (B)	$\overline{\mathbf{y}}$
White (W)	
Willie (W)	lacksquare
250 m reel	
250 III reei	
FOO m rool	
500 m reel	-

Specifications

Fluid		Air, Water		
Max. operating Note 1) pressure (MPa)	20°C or less	3.0		
	40°C	2.1		
	60°C	1.5		
	80°C	1.25		
	100°C	1.1		
Applicable fitting	s Note 1) Note 2)	One-touch fittings, Insert fittings, Self-align fittings, Miniature fittings		
Min. bending radius	Min. bending radius	24		
(mm) Note 3)	Bending value (Reference)	18		
Operating tempe	rature Note 1)	-40 to +100°C, Water: 0 to +70°C (No freezing)		
Material		Nylon 12		

- Note 1) Be sure to operate under the maximum operating pressure and operating temperature conditions using the lower specifications of either the tubing or fittings.
- Note 2) Mount an inner sleeve when using metal One-touch fittings in high-temperature environments of 60°C or more. Use self-align fittings at a temperature of 60°C or less.
- Note 3) The minimum bending radius is the representative value measured as shown in the left figure.
 - · Use a tube above the minimum bending radius.
 - The tubing may be bent if used under the minimum bending radius. Therefore, refer to the bending value and make sure that the tubing is not bent or flattened.
 - Please note that the bending value is not warranted because of the representative value when 2R is measured by the method in the left figure if the tubing is bent or flattened, etc.

How to Order



⚠ Precautions

Be sure to read this before handling. For Safety Instructions and Fittings I and Tubing Precautions, refer to "Handling Precautions for SMC I Products" on SMC website, http://www.smcworld.com

∧ Caution

- Applicable for general industrial water. Please consult with SMC if using other kinds of fluid.
 Surge pressure must be under the max. operating pressure. If the surge pressure exceeds the maximum operating pressure, it will result in damage to fittings and tubes.
- Please exercise caution when using this item in a clean room. There is a possibility of plasticizer and other materials precipitating on the tube surface and detracting from the cleanliness level of the room.



Reinforced Corrugated Cardboard Specification/Longer Length Reel

FEP Tubing (Fluoropolymer)

TH0604-X64



• Length per roll: 500/250 m

Operating temperature: Max. 200°C

It varies depending on the operating pressure. Refer to the graph for the maximum operating pressure.

Compatible with the Food Sanitation Law


- Compatible with the test conforming to the Food Sanitation Law based on the 370th notice given by the Ministry of Health and Welfare in 1959.
- Complies with FDA (Food and Drug Administration) §177-1550 dissolution test

How to measure the minimum bending radius



At a temperature of 20°C, bend the tubing into a U shape. Fix one end and gradually move the other end closer. Measure 2R at the point where the outside diameter's rate of change is 5%.

Max. Operating Pressure



Note) The maximum operating pressure varies dependent on the I.D. bore size even if the O.D. is the same.

Series

Model	TH0604
Tubing O.D. (mm)	6
Tubing I.D. (mm)	4
Translucent (N)	
	Ī
250 m reel	•
500 m reel	
Joo III Teel	Y

Specifications

Fluid		Air, Water Note 1), Inert gas		
Applicable fittings Note 2)		One-touch fittings, Insert fittings Fluoropolymer fittings: Series LQ Note 3) Miniature fittings: Series M, MS (Hose nipple type)		
	20°C	1.5		
Max. operating	100°C	0.55		
pressure (MPa)	200°C	0.3		
		Refer to below "Max. Operating Pressure."		
Min. bending radius	Min. bending radius	35		
(mm) Note 4)	Bending value (Reference)	20		
Operating temperature		Air, Inert gas: -20 to 200°C, Water: 0 to 100°C (No freezing)		
Material		FEP (Fluorinated Ethylene Propylene Resin)		

Note 1) When using a fluid in liquid form, the surge pressure must not exceed the maximum operating pressure. A surge pressure higher than the maximum operating pressure can cause breakage of the fittings, or rupture of the tubing.

Furthermore, an abnormal temperature increase due to adiabatic compression can also result in ruptured tubing.

Note 2) Do not use in locations where the FEP tubing will move.

Be sure to operate under the maximum operating pressure and operating temperature conditions using the lower specifications of either the tubing or fittings.

After long term use or under high temperatures, some fittings leakage may occur due to material deterioration with age. Perform periodic inspections, and if any leakage is detected, replace with a new product immediately.

When the insert and miniature fittings are used over extended periods of time, it may cause leakage due to the material deterioration of age. In such a case, give an additional tightening to the tube connection part. If leakage still occurs after giving an additional tightening, replace the fitting with a new product.


For other precautions, refer to "Fittings & Tubing Precautions." When using the fluoropolymer fittings, refer to the precautions for fluoropolymer fittings in Best Pneumatics No. 6. Select the size after confirming O.D. and I.D.

Note 3) Not applicable to the TH1075 since the I.D. is different.

Note 4) The minimum bending radius is the representative value measured as shown in the left figure.


- · Use a tube above the recommended minimum bending radius.
- The tubing may be bent if used under the recommended minimum bending radius. Therefore, refer to the bending value and make sure that the tubing is not bent or flattened.
- · Please note that the bending value is not warranted because of the value when 2R is measured by the method in the left figure if the tubing is bent or flattened, etc.

How to Order



T0604-X64/TH0604-X64

Dimensions



Dimensions

Model	ø D 1	ø D2	ø D3	w	Weight (kg)
T0604□-250-X64	475	200	52	120	5.1
T0604□-500-X64	475	200	52	200	9.4
TH0604N-250-X64	475	200	52	120	9.4
TH0604N-500-X64	475	200	52	220	18.5

Tubing Best Pneumatics

Polyurethane Coil Tubing *TCU*

- •Max. operating pressure: 0.8 MPa or less (at 20°C)
- For moving applications



Series	Tubing O.D.	Color	Number of cores	Fluid
TCU	ø4, ø6, ø8	Black	1, 2, 3	Air

Note) Colors other than black are available as Made-to-Order specifications.

Longer Length Reel/-X3 Made to Order (Please contact SMC for specifications in detail, dimensions, delivery and specifications other than those mentioned above.)

Nylon tubing

100 m reel

Metric size and Inch size except ø16: Suffix "-X3" to the end of part number.

Ex.) T0425R-100-X3

100/150/200/500 m reel

Metric size: Suffix "-X3" to the end of part number.

Ex.) T0425G-500-X3

Made to Order Availability

Part no.	Length Model	T0425*	T0604*	T0806*	T1075*	T1209*	TIA01*	TIA05*	TIA07*	TIA11*	TIA13*	Color
ХЗ	100 m reel	0	0	0	0	0	0	0	0	0	0	Black, White,
	150 m reel				0							Red, Blue,
	200 m reel			0								
	500 m reel	0	0									Yellow, Green

Fittings/S Couplers

Stainless Steel 316 One-touch Fittings KQG2

- Metal parts: Stainless steel 316 Seal parts: Special FKM
- Fluid temperature: -5 to 150°C
- Grease-free
- •Can be used with steam.



Series	Applicable tubing O.D.	Operating pressure range	Connection thread
KOCO	ø3.2, ø4, ø6, ø8 ø10, ø12, ø16	100 kPa to 1 MPa	M, R, Rc
KQG2	ø1/8", ø5/32", ø1/4" ø5/16", 3/8", ø1/2"	- 100 KFA tO 1 MPA	UNF, NPT

Stainless Steel 316 Insert Fittings KFG2

- Material: Stainless steel 316
- (Swivel elbow: Stainless steel 316, Special FKM)
- Fluid temperature: -65 to 260°C (Swivel elbow: -5 to 150°C)
- Grease-free
- •Can be used with steam.



Best Pneumatics

Series	Applicable tubing O.D.	Operating pressure range	Connection thread
KFG2	ø4 x ø2.5, ø4 x ø3, ø6 x ø4 ø8 x ø6, ø10 x ø7.5, ø10 x ø8 ø12 x ø9, ø12 x ø10, ø16 x ø13	–100 kPa	R, Rc
KFGZ	Ø1/8" x Ø0.086", Ø5/32" x Ø0.098" Ø1/4" x Ø5/32", Ø5/16" x Ø0.236" Ø3/8" x Ø1/4", Ø1/2" x Ø3/8"	to 1 MPa	NPT

S Couplers: Stainless Steel Type KKA

- Body material: Stainless steel 304
- Seal material: Fluororubber (Special FKM)
- Fluid temperature: -5 to 150°C
- Grease-free



0	Port size								
Series	R, Rc1/8	R, Rc1/4	R, Rc3/8	R, Rc1/2	R, Rc3/4	R, Rc1	R, Rc1 1/4	R, Rc1 1/2	
KKA3	•	•	•						
KKA4		•	•	•					
KKA6			•	•	•				
KKA7				•	•	•			
KKA8					•	•	•		
KKA9						•	•	•	









Revision history

- Edition B Models listed in the catalog added. (IP8000, IP5000, CPA2, VFN, etc.)
 - Specific Product Precautions, Safety Instructions added.
 Number of pages increased from 12 to 116.

⚠ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)*1), and other safety regulations.

Caution indicates a hazard with a low level of risk Caution: which, if not avoided, could result in minor or moderate injury.

Warning indicates a hazard with a medium level of ** Warning: risk which, if not avoided, could result in death or serious injury.

⚠ Danger :

Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

*1) ISO 4414: Pneumatic fluid power – General rules relating to systems. ISO 4413: Hydraulic fluid power – General rules relating to systems. IEC 60204-1: Safety of machinery - Electrical equipment of machines. (Part 1: General requirements)

ISO 10218-1: Manipulating industrial robots - Safety.

⚠ Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications. Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
 - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
 - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following
 - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
 - 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
 - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

⚠ Caution

1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.

If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/ **Compliance Requirements**

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.*2)
 - Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.
 - 2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

⚠ Caution

SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

▲ Safety Instructions | Be sure to read "Handling Precautions for SMC Products" (M-E03-3) before using.

SMC Corporation

Akihabara UDX 15F

4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN Phone: 03-5207-8249 Fax: 03-5298-5362

http://www.smcworld.com

© 2014 SMC Corporation All Rights Reserved